




POLYURETHANE
MACHINERY CORPORATION

Premier Proportioner Service Manual

Ref. # 203332
Revision 1.0



FOR PROFESSIONAL USE ONLY
Not approved for use in European explosive atmosphere locations

1 Komo Dr.
Lakewood, NJ 08701
Phone: 732-415-4400
URL: <http://www.polymacusa.com>

I. Table of Contents

I.	Table of Contents	2
II.	List of Figures	5
1	WARRANTY	9
2	SAFETY AND HANDLING.....	11
3	CHARACTERISTICS	13
3.1	PRINCIPAL HEATING SYSTEM.....	13
3.2	HOSE HEATING SYSTEM.....	13
3.3	DOUBLE ACTING OPPOSED PISTON METERING PUMPS.....	13
3.4	PRESSURE BALANCE CONTROL SYSTEM	14
4	TECHNICAL SPECIFICATIONS.....	15
4.1	ELECTRICAL	15
4.2	MECHANICAL.....	16
5	DESCRIPTION.....	17
6	HMI LAYOUT & USAGE	22
6.1	WIDGET SETPOINT VALUES	22
6.2	GENERAL SCREEN INFORMATION	23
6.2.1	COMMON WIDGET TRENDS.....	23
6.3	MACHINE SCREEN.....	25
6.3.1	A/B EXIT PRESSURE.....	25
6.4	JOB SETUP SCREEN	28
6.4.1	A/B SIDE DRUM COUNTER.....	28
6.4.2	A/B SIDE INLET TEMPERATURE.....	29
6.4.3	A/B SIDE INLET PRESSURE.....	29
6.4.1	RATIO CONFIRMATION.....	29
6.4.2	DRUM ALARM.....	30
6.5	REPORT SCREENS.....	31
6.5.1	RECORD ON LIGHT.....	31
6.5.2	RECORD TIME	31
6.5.3	MANUAL START REPORT RECORDING.....	32
6.5.4	MANUAL STOP REPORT RECORDING.....	32
6.5.1	EMAIL ADDRESS DIRECTORY	33
6.5.2	SEND EMAIL.....	33
6.5.3	REPORT SETTINGS.....	34
6.5.4	USB DOWNLOAD.....	34
6.5.5	TEMPERATURE CONDITIONS	35
6.5.6	PRESSURE CONDITIONS.....	35
6.5.7	CHEMICAL USED	36
6.6	MAINTENANCE SCREEN.....	37
6.6.1	ANALOG INPUTS	37
6.6.1	DIGITAL INPUTS.....	38
6.6.2	DIGITAL OUTPUTS	38

6.6.3	THERMAL INPUTS 1	38
6.6.4	THERMAL INPUTS 2	39
6.6.5	FLOW SENSOR INPUTS.....	39
6.6.6	MACHINE SETPOINT RESET	39
6.6.7	MACHINE SERIAL NUMBER	40
6.6.8	MACHINE LIFETIME CYCLE COUNT	40
6.6.9	SOFTWARE VERSION	40
6.6.10	SUPPORT	40
6.7	EVENTS SCREEN	41
6.7.1	EVENT LOG.....	41
6.7.2	AUDIT VIEW	42
7	NETWORK CONNECTION.....	43
8	REMOTE ACCESS.....	44
8.1	CORVINA LOGIN	44
8.2	ACCESSING THE MACHINE	45
9	FLOW METERS.....	47
9.1	CALIBRATION.....	47
10	JOB REPORTS	48
10.1	EXPRESS REPORT.....	48
10.2	DETAILED REPORT	51
10.3	CAPTURING REPORTS	52
10.4	SENDING REPORTS.....	54
10.4.1	EMAILING REPORTS.....	54
10.4.2	USB SAVING.....	54
11	INSTALLATION.....	56
11.1	HEATED HOSE INSTALLATION	58
11.2	HOSE HEAT TRANSFORMER.....	61
12	START-UP	62
13	PROPORTIONER PURGING.....	63
14	MACHINE STOP	65
14.1	IDLE	65
14.2	SHUT DOWN	65
15	TROUBLESHOOTING.....	66
15.1	HEATERS	67
15.2	HYDRAULIC DRIVE SYSTEM	70
15.3	METERING PUMP LINE	72
15.4	HOSE HEATING.....	76
15.5	PRESSURE BALANCE CONTROL	78
16	MAINTENANCE.....	79
16.1	PMC MAINTENANCE SCHEDULE.....	80

16.2	INLET MATERIAL SCREENS	81
16.3	ISO LUBRICATION SYSTEM.....	82
16.4	HYDRAULIC DRIVE SYSTEM.....	83
16.5	METERING PUMP-LINE	84
16.6	PUMP BASE SERVICE	84
16.7	PUMP SEAL REPLACEMENT	85
16.8	METERING PUMP REMOVAL.....	85
16.9	MATERIAL HEATER.....	86
16.10	THERMOCOUPLE REPLACEMENT	86
17	HYDRAULIC OIL SPECIFICATIONS	88
17.1	MANUFACTURERS.....	88
18	PARTS IDENTIFICATION.....	89
18.1	FRAME ASSEMBLY.....	89
18.2	PROX SENSOR ASSEMBLY	91
18.3	PUMP-LINE ASSEMBLY.....	92
18.3.1	PUMP BASE REBUILD KITS.....	93
18.4	HYDRAULIC CYLINDER ASSEMBLY	94
18.4.1	HYDRAULIC CYLINDER REBUILD KIT	95
18.4.2	HYDRAULIC CYLINDER ASSEMBLY BASE	96
18.5	A SINGLE PUMP ASSEMBLY	98
18.5.1	A SINGLE REBUILD KIT.....	99
18.6	B SINGLE PUMP ASSEMBLY	100
18.6.1	B SINGLE PUMP SEALS.....	101
18.7	A & B PUMP BASE ASSEMBLY.....	102
18.8	INLET MONITORING ASSEMBLY	103
18.9	Y-STRAINER ASSEMBLY "A" SIDE.....	104
18.10	Y-STRAINER ASSEMBLY "B" SIDE	105
18.11	HEATER ASSEMBLY.....	106
18.12	PRESSURE TRANSDUCER ASSEMBLY	109
18.13	MOTOR-LINE ASSEMBLY	110
18.14	A FLOW METER PIPES.....	112
18.15	B FLOW METER PIPES.....	113
18.16	CONSOLE ASSEMBLY.....	114
18.16.1	HIGH VOLTAGE PLATE ASSEMBLY	119
18.16.2	PLC PLATE ASSEMBLY	120
18.17	FINAL ASSEMBLY.....	121
18.18	PREMIER HOSES	128
18.18.1	HALF INCH HOSE KIT.....	129
18.19	LUBE BOTTLE COMPONENTS.....	130
18.20	BLEED VALVES	131

II. List of Figures

Figure 1: Hose Heating Diagram	13
Figure 2: Pressure Balance Control Logic Diagram	14
Figure 3: Proportioner Dimensions	16
Figure 4: Component Identification - Front.....	17
Figure 5: Component Identification - Back	18
Figure 6: Front Panel Description	20
Figure 7: Transformer Enclosure	21
Figure 8: Controls Widget Reference	23
Figure 9: E-Stop	23
Figure 10: Active Alarm	23
Figure 11: +/- Buttons.....	23
Figure 12: Actual Values vs. Setpoints	23
Figure 13: Input Keyboard	23
Figure 14: Inactive Button	24
Figure 15: Active Button	24
Figure 16: Exit Pressure Gauge.....	24
Figure 17: Drum Level Gauge	24
Figure 18: Machine Screen	25
Figure 19: A Side Exit Pressure	25
Figure 20: B Side Exit Pressure	25
Figure 21: A Side Heater.....	26
Figure 22: Hose Heater	26
Figure 23: B Side Heater.....	26
Figure 24: Countdown Counter	26
Figure 25: Cycle Counter	26
Figure 26: Pump Control Off.....	27
Figure 27: Pump Control Retract.....	27
Figure 28: Pump Control On w/ Retract On	27
Figure 29: Pump Control On w/ Normal On.....	27
Figure 30: Motor Enable.....	27
Figure 31: Pressure Balance Control.....	27
Figure 32: Job Setup Screen	28
Figure 33: A Side Drum Counter	28
Figure 34: B Side Drum Counter	28
Figure 35: A Side Inlet Temperature	29
Figure 36: B Side Inlet Temperature	29
Figure 37: A Inlet Pressure.....	29
Figure 38: B Inlet Pressure.....	29
Figure 39: Ratio Confirmation	29

Figure 40: Low Drum Alarm	30
Figure 41: Reports Screen	31
Figure 42: Recording Active Light.....	31
Figure 43: Recording Inactive Light	31
Figure 44: Recording Report Time.....	31
Figure 45: Start Recording Button	32
Figure 46: Start Report Recording Window.....	32
Figure 47: Stop Recording Button.....	32
Figure 48: Stop Recording Window.....	32
Figure 49: Email Directory	33
Figure 50: Send Email Button	33
Figure 51: Send Email Window	33
Figure 52: Report Settings Button.....	34
Figure 53: Report Storage Window	34
Figure 54: USB Download Button.....	34
Figure 55: USB Download Window.....	34
Figure 56: Reports Temperature Conditions	35
Figure 57: Reports Pressure Conditions.....	35
Figure 58: Report Maintenance Screen	37
Figure 59: PLC Analog Inputs.....	37
Figure 60: PLC Digital Inputs.....	38
Figure 61: PLC Digital Outputs	38
Figure 62: PLC Thermal Inputs 1	38
Figure 63: PLC Thermal Inputs 2.....	39
Figure 64: PLC Flow Sensor Inputs.....	39
Figure 65: Machine Setpoint Reset Button	39
Figure 66: Machine Setpoint Reset Confirmation Window	39
Figure 67: Machine Serial Number.....	40
Figure 68: Lifetime Cycle Count	40
Figure 69: PLC Software Version	40
Figure 70: Support Screen	40
Figure 71: Events Screen.....	41
Figure 72: Alarms History Table	41
Figure 73: Audit View Table	42
Figure 74: IMEI Number.....	43
Figure 75: Corvina Login Page.....	44
Figure 76: Corvina Active Machine Screen	45
Figure 77: Corvina Active Machine Icons	45
Figure 78: Active Gateway VNC Connection.....	45
Figure 79: Machine Gateway and Organization	46

Figure 80: Flow Meters Step 2	47
Figure 81: Flow Meters Step 3	47
Figure 82: Flow Meters Step 4	47
Figure 83: Flow Meters Step 5	47
Figure 84: Report Information Heading.....	48
Figure 85: Temperature Conditions Chart - Inlet & Exit.....	48
Figure 86: Temperature Conditions Chart – Hose	48
Figure 87: Temperature Condition Data.....	48
Figure 88: Pressure Condition Chart - Inlet & Exit	49
Figure 89: Pressure Condition Data.....	49
Figure 90: Chemical Condition Chart - Chemical Ratio & Chemical Used	49
Figure 91: Chemical Condition Data	50
Figure 92: Temperature Condition Logged Data	51
Figure 93: Pressure Condition Logged Data.....	51
Figure 94: Chemical Conditions Logged Data	52
Figure 95: Start Report Flow Chart.....	53
Figure 96: Generate Report Flow Chart	53
Figure 97: Emailing & Saving Report Flow Chart.....	55
Figure 98: Incoming Electrical Power Connection.....	56
Figure 99: Installation	57
Figure 100: Temperature Sensing Unit	59
Figure 101: Transformer Tap Settings	61
Figure 102: Metering Pump-Line.....	72
Figure 103: Inlet Strainer Components.....	81
Figure 104: ISO Lubrication System	82
Figure 105: Thermocouple Identification	86
Figure 106: Frame Assembly (203097)	89
Figure 107: Prox. Sensor Assembly (RM-230)	91
Figure 108: Pump-Line Assembly (PL-1A)	92
Figure 109: Hydraulic Cylinder Assembly (HI-01)	94
Figure 110: Hydraulic Cylinder Assembly Base (HI-05025A).....	96
Figure 111: Hydraulic Seal Detail View	97
Figure 112: Hydraulic Piston Detail View	97
Figure 113: A Single Pump Assembly (PU-05001-120).....	98
Figure 114: A Single Pump Cross Section.....	99
Figure 115: B Single Pump Assembly (PU-05002-120).....	100
Figure 116: B Single Pump Cross Section.....	101
Figure 117: A & B Pump Base Assembly (202520)	102
Figure 118: Inlet Monitoring Assembly (202237).....	103
Figure 119: Y-Strainer Assembly "A" Side (YS-1).....	104

Figure 120: Y-Strainer Assembly "B" Side (YS-2).....	105
Figure 121: Heater Assembly, 6 Rod - A.....	106
Figure 122: Heater Assembly, 6 Rod - B.....	106
Figure 123: 6 Rod Heater Assembly, A and B Side.....	108
Figure 124: Pressure Transducer Assembly (EL-200).....	109
Figure 125: Motor-Line Assembly (ML-4).....	110
Figure 126: Flow Meter Pipe - A-Side (203232).....	112
Figure 127: Flow Meter Pipe - B-Side (203233).....	113
Figure 128: Console Assembly - A.....	114
Figure 129: Console Assembly - B.....	115
Figure 130: Console Assembly - C.....	116
Figure 131: High Voltage Plate Assembly (203048).....	119
Figure 132: PLC Plate Assembly (203049).....	120
Figure 133: Premier Final Assembly - A.....	121
Figure 134: Premier Final Assembly - B.....	122
Figure 135: Premier Final Assembly - C.....	123
Figure 136: Premier Final Assembly - D.....	124
Figure 137: Proportioner Hoses - Front.....	128
Figure 138: Proportioner Hoses - Back.....	128
Figure 139: Lube Bottle Components.....	130
Figure 140: Bleed Valves (202455).....	131

1 WARRANTY

Polyurethane Machinery Corporation (hereinafter “PMC”) provides this **LIMITED WARRANTY** (hereinafter “Warranty”) to the original purchaser (hereinafter “Customer”) covering this equipment and the original PMC manufactured accessories delivered with the equipment (hereinafter “Product”) against defects in material or workmanship of the Product (hereinafter “Defect” or “Defective”) for a period of one (1) year from the date of first purchase as shown on the original PMC invoice (hereinafter “Warranty Period”)

If during the Warranty Period under normal use, the Product is suspected by Customer to be Defective in material or workmanship, it is Customer’s responsibility to contact PMC and return the Product to PMC as directed by PMC, freight prepaid. If PMC determines that the Product is Defective and that such Defect is covered by this Warranty, PMC will credit Customer for the reasonable freight charges incurred by Customer in returning the Defective Product to PMC, and PMC (or its authorized agent) will, at PMC’s option, repair or replace the Product, subject to the following:

1. Original Invoice: The original invoice must be kept as proof of the date of first sale and the Product serial number. The Warranty does not cover any Product if the Original Invoice appears to have been modified or altered, or when the serial number on the Product appears to have been altered or defaced.
2. Product Maintenance: It is the Customer’s responsibility to maintain the Product properly. See your maintenance schedule and owner’s manual for details. The Warranty does not cover an improperly maintained Product.
3. Non-PMC Components and Accessories: Non-PMC manufactured components and accessories that are used in the operation of the Product are not covered by this Warranty. Such components and accessories shall be subject to the warranty offered to the Customer, if any, by the original manufacturer of such component or accessory.
4. Other Warranty Exclusions: The Warranty does not cover any Product that PMC determines has been damaged or fails to operate properly due to misuse, negligence, abuse, carelessness, neglect, or accident. By way of example only, this includes:
 - Normal wear and tear.
 - Improper or unauthorized installation, repair, alteration, adjustment, or modification of the product.
 - Use of heating devices, pumping equipment, dispensers, or other parts or accessories with the product that have not been approved or manufactured by PMC.
 - Failure to follow the operating instructions and recommendations provided by PMC.
 - Cosmetic damage.
 - Fire, flood, “acts of God”, or other contingencies beyond the control of PMC.

THE WARRANTY DESCRIBED HEREIN IS THE EXCLUSIVE REMEDY FOR THE CUSTOMER AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS, IMPLIED, STATUTORY OR OTHERWISE, AND THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE AND ALL OTHER WARRANTIES ARE HEREBY DISCLAIMED. TO THE FULLEST EXTENT PERMITTED BY LAW, PMC SHALL NOT BE RESPONSIBLE, WHETHER BASED IN CONTRACT, TORT (INCLUDING, WITHOUT LIMITATION, NEGLIGENCE), WARRANTY OR ANY OTHER LEGAL OR EQUITABLE GROUNDS, FOR ANY CONSEQUENTIAL, INDIRECT, INCIDENTAL, LOST PROFITS, SPECIAL, PUNITIVE OR EXEMPLARY DAMAGES, WHETHER TO PERSON OR PROPERTY, ARISING FROM OR RELATING TO THE PRODUCT, EVEN IF PMC HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH LOSSES OR DAMAGES.

- Non-Warranty Service by PMC: If PMC determines that the suspected Defect of the Product is not covered by this Warranty, disposition of the Product will be made pursuant to the terms and conditions of PMC's written estimate on a time and materials basis.
- Continuing Warranty for Products Repaired or Replaced under Warranty: Following the repair or replacement of a Product covered by this Warranty, such Product will continue to be subject to the original Warranty for the remainder of original Warranty Period or for three (3) months from the repair or replacement date, whichever is longer.
- No Rights Implied: Nothing in the sale, lease or rental of any Product by PMC shall be construed to grant any right, interest, or license in or under any patent, trademark, copyright, trade secret or other proprietary right or material owned by anyone; nor does PMC encourage the infringement of same.
- Exclusive Warranty: This writing is the final, complete, and exclusive expression of the Warranty covering the Product. Any statements made by PMC, its employees or agents that differ from the terms of this Warranty shall have no effect. It is expressly understood that Customer's acceptance of this Warranty, by performance or otherwise, is upon and subject solely to the terms and conditions hereof, and any additional or different terms and conditions proposed or expressed by Customer or anyone, whether in writing or otherwise, are null and void unless specifically agreed to in writing by an Officer of PMC.

2 SAFETY AND HANDLING

This chapter contains important information on the safety, handling, and use of your Premier Series Proportioner.

	Before installing the Premier Series Proportioner and startup, carefully read all the technical and safety documentation included in this manual. Pay special attention to the information in order to know and understand the operation and the conditions of use of the Premier Series Proportioner. All of the information is aimed at improving user safety and avoiding possible breakdowns from the incorrect use of the Premier Series Proportioner.
---	---

WARNING! Symbol is presented in front of information to alert of a situation that might cause serious injuries if the instructions are not followed.

CAUTION! Symbol is presented in front of information that indicates how to avoid damage to the proportioner or how to avoid a situation that could cause issues.

NOTE! Symbol is presented in front of relevant information of a procedure being carried out.

Careful study of this manual will enable the operator to know the characteristics of the Premier Series Proportioner and the operating procedures. By following the instructions and recommendations contained herein, you will reduce the potential risk of accidents in the installation, use, and maintenance of the Premier Series Proportioner. You will provide a better opportunity for greater output, incident-free operation for a longer time, and the possibility of detecting and resolving problems quickly and simply.

Keep this Operations Manual for future consultation of useful information. If you lose this manual, ask for a new copy from your PMC Service Center or go online at our web site (www.polymacusa.com).

The Premier Series Proportioner has been designed and built for the application of polyurethane foam chemical systems, and some two-component epoxy systems

WARNING! The design and configuration of the Premier Series Proportioner does not allow its use in potentially explosive atmospheres, or the pressure and temperature limits described in the technical specifications of this manual to be exceeded.

Always use liquids and solvents that are compatible with the unit. If in doubt, consult your authorized PMC distributor.

When working with the Premier Series Proportioner, it is recommended that the operator wear suitable clothing and elements of personal protection, including, without limitation, gloves, protective goggles, safety footwear and face masks. Use breathing equipment when working with the Premier Series Proportioner in enclosed spaces or in areas with insufficient ventilation. The introduction and follow-up of safety measures must not be limited to those described in this manual. Before starting up the Premier Series Proportioner, a comprehensive analysis must be made of the risks derived from the products to be dispensed, the type of application, and the working environment.

	<i>To prevent possible injury caused by incorrect handling of the raw materials and solvents used in the process, carefully read the Safety Data Sheet (SDS) provided by your supplier. Deal with the waste caused according to current regulations.</i>
	<i>To avoid damage caused by the impact of pressurized fluids, do not open any connection, or perform maintenance work on components subject to pressure until the pressure has been completely eliminated.</i>
	<i>Use suitable protection when operating, maintaining or being present in the area where the equipment is functioning. This includes, but is not limited to, the use of protective goggles, gloves, shoes, and safety clothing and breathing equipment.</i>
	<i>The equipment includes components that reach high temperatures and can cause burns. Hot parts of the equipment must not be handled or touched until they have cooled completely.</i>
	<i>To prevent serious injury through crushing or amputation, do not work with the equipment without the safety guards installed on the moving parts. Make sure that all the safety guards are correctly reinstalled at the end of the repair or maintenance work of the equipment.</i>

3 CHARACTERISTICS

The Premier Series Proportioner has been designed and built for the application of polyurea chemical systems, polyurethane foam chemical systems, and some specific two-component epoxy systems.

3.1 PRINCIPAL HEATING SYSTEM

The Proportioner consists of two (2) independent Material Heaters without internal seals. Each Heater six (6) Heating Elements rated at 1,500 Watts each, giving the Proportioner a total heat output of 18,000 Watts. The heating system provides the necessary control and safety components for their precise operation. The Material Heater design allows for a controlled and precise temperature differential (ΔT) of 90 ° F (32 ° C) and material application temperatures of up to 190° F (88 ° C) under ambient temperatures.

3.2 HOSE HEATING SYSTEM

The system is designed with a 5 KVA (120 V) Isolation Transformer that enables effective heating of up to a total hose length of 410 feet (123 meters). The system includes an innovative hose heating concept in which the continuous braid tinned-copper jacket is distributed evenly around the circumference of the hose providing a uniform heating watt density and precise control of the material application temperature. This hose heating element design is extremely resistant to fatigue failure.

100% circumferential coverage produces the most uniform distribution of heat available.



Figure 1: Hose Heating Diagram

3.3 DOUBLE ACTING OPPOSED PISTON METERING PUMPS

The opposed double acting Pump Line is driven by a double ended Hydraulic Cylinder. The in-line pump system with opposed piston pumps provides a constant volume and guarantees uniform pressures in both directions of pump movement.

3.4 PRESSURE BALANCE CONTROL SYSTEM

The Pressure Balance Control (PBC) system performs an automatic shutdown when a chemical imbalance occurs. When the system is turned off, the Proportioner will perform as if there is no PBC system and will continue pumping material. When the system is turned on, it will continually monitor the pressure between the two chemicals (known as the **pressure differential**). If the pressure differential becomes equal to or greater than the **maximum allowable pressure differential**, the pumps will be shut off.

The Pressure Balance Control system can be simplified into a logic box diagram with inputs and outputs. There are five inputs: the power supply from the main console, the pressure readings from each chemical, the maximum pressure, and the maximum allowable pressure differential. Inside the logic box, the actual pressure differential of the chemicals is compared to the maximum allowable pressure differential. Depending on the circumstances of all five inputs, there are only two possible outputs: either the pumps will continue to pressurize and move material, or the pumps will shutoff and flow will be lost.

See Section 6.3.1.6 on Page 27 for the pressure balance control widget located in the HMI.




Figure 2: Pressure Balance Control Logic Diagram

4 TECHNICAL SPECIFICATIONS

4.1 ELECTRICAL

Premier Detailed Electrical Specifications

Material Heater Power	Power Consumption
18.0kW (9.0kW [6x1500W]/side)	18.0kW
Hose Transformer	
120V	4.25kW
Electrical Motor	
Premier	4.21kW
Console	
All	.12kW
Total	12.58kW



CAUTION! Inside the console is a Terminal Strip for connecting the main power (wire not supplied) to the Premier Series Proportioner. This electrical connection must be made only by a qualified electrician.

Premier Total Electrical Consumption

Material Heater Power	Hose Transformer	Electrical Motor	Total Electrical Consumption
18.0kW	120V	5HP	66.72A

NOTES: Calculations for 200-240VAC specifications based off a 230VAC input.

4.2 MECHANICAL

120 Pumps	
Maximum Working Pressure	2,000PSI (14MPa, 138bar)
Maximum Production	40lb/min (14kg/min)
Minimum Production	2lb/min (1kg/min)
Volume per Cycle (Single Pump)	0.0312gal/cycle (0.1181L)
Volume per Cycle (Both Pumps)	0.0624gal/cycle (0.2362L)
Cycles per 55gal (200L) Drum	1,763 cycles
Maximum Hose Length	
5KVA Transformer	410ft (125m)
Approximate Weight	
Hydraulic Tank Empty	670 lbs. (304 kg)
Hydraulic Tank Full (20gal)	844 lbs. (383 kg)
Overall Dimensions (W x D x H)	
30in x 40in x 55in (76cm x 102cm x 140cm)	





Figure 3: Proportioner Dimensions

5 DESCRIPTION




Figure 4: Component Identification - Front




Figure 5: Component Identification - Back

A. Control Panel

Controls and regulates the operation of the Premier Series Proportioner.

B. Isocyanate (Iso, A) Metering Pump

Meters the Isocyanate material.

C. Polyol (Poly, B) Metering Pump

Meters the Polyol material.

D. Hydraulic Cylinder Manifold

Transfers power from hydraulic pump to material pumps.

E. Isocyanate (Iso, A) Inlet Manifold Assembly

Provides Isocyanate temperature and pressure readings prior to heating and pressurizing.

F. Polyol (Poly, B) Inlet Manifold Assembly

Provides Polyol temperature and pressure readings prior to heating and pressurizing.

G. Isocyanate (Iso, A) Recirculation Valve

Separate ball valves allow the user to recirculate Isocyanate back into the barrel for reheating purposes or to purge the Proportioner of remaining Isocyanate.

H. Polyol (Poly, B) Recirculation Valve

Separate ball valves allow the user to recirculate Polyol back into the barrel for reheating purposes or to purge the Proportioner of remaining Polyol.

I. Iso (Iso, A) Flow Meter

Provides flow reading of Isocyanate after heating and pressurizing.

J. Polyol (Poly, B) Flow Meter

Provides flow reading of Polyol after heating and pressurizing.

K. Isocyanate (Iso, A) Material Exit Assembly

Provides pressure reading of Isocyanate after heating and pressurizing.

L. Polyol (Poly, B) Material Exit Assembly

Provides pressure reading of Polyol after heating and pressurizing.

M. Lube Reservoir

Provides PMC approved lube to the "A" Side Pump Shaft to avoid crystallization build-up.

N. Hydraulic Pressure Control

Allows the pressure of the hydraulic system to be increased or decreased. Turn clockwise to increase pressure and counterclockwise to decrease. To regulate the pressure of the hydraulic system, the NORMAL or RETRACT pump switch position must be selected.

O. Hydraulic Manifold Assembly

Provides pressure reading of hydraulic fluid and controls direction of flow.

P. Motor

Provides power to hydraulic pump.

Q. Inlet Material Strainer

Screens (60 mesh) material from bulk supply.




Figure 6: Front Panel Description

R. Main Power Switch

Turns ON and OFF main power to the control panel. It must be turned ON for any operation to be performed with the unit.

The Green indicator light (V) indicates that the main power switch is ON.

S. USB Port

Connects USB devices to the machine and give the user the ability to export job reports.

T. Power On Light

Green indicator light indicates whether the main power for the machine is turned ON or OFF.

U. Emergency Stop Button

Interrupts the Premier-Series control power circuit to stop all motion and heating.

Activate – Press the Emergency Stop Button down to stop all motion and heating.

Deactivate – Twist the Emergency Stop Button CLOCKWISE to release.

V. Antenna

Connects the machine to the internet service provider (ISP) and gives the user the ability to use the machines network capabilities.




Figure 7: Transformer Enclosure

- W. Voltage Indicator Light**
Red Indicator Light that will light up when voltage is being supplied to the transformer.
- X. Amps Indicator Light**
White Indicator Light that will light up when the transformer is actively heating up the hose.
- Y. ICL (Inrush Current Limiter)**
A safety fuse that will pop and keep the circuit open if there is too much voltage to the primary side of the hose transformer.
- Z. SSR (Solid State Relay)**
Completes the hose heat circuit allowing amps to flow through the hose heat wires. The DC side is controlled by the Hose Heat Controller within the console.
- AA. CT (Current Transformer)**
Senses amperage flow on the load side of the Hose Heat Breaker, which powers the Amps indicator Light.
- BB. Hose Heat Circuit Breaker**
63A Single Pole circuit breaker that protects the Heated Hose from over-amping.
- CC. Hose Heat Transformer**
Provides power to hose heat. The transformer provides different output voltages depending on hose length. See further information in section 11.2.

6 HMI LAYOUT & USAGE

6.1 WIDGET SETPOINT VALUES

HMI Widget Setpoint Values			
Widget Description	Allowable Data Ranges		Operating Maximums
	<u>Min.</u>	<u>Max</u>	
A/B Exit Pressure Gauge (PSI)	0	2500	2250
A/B Temperature Control (°F)	0	200	200
Hose Temperature Control (°F)	0	200	200
Hose Temperature Control Manual Mode (%)	0	100	100
Countdown Counter	0	9999	9999
Pressure Balance Control (PSI)	0	3500	1000
Drum Counter Gauge (Gal)	0	55	Drum Dependent
Drum Counter Max Capacity (Gal)	0	55	Drum Dependent
Drum Counter Drum Level (Gal)	0	55	Drum Dependent
Drum Alarm Setpoints (Gal)	0	55	Drum Dependent
A/B Inlet Temperature Data (°F)	0	200	Rig Dependent
A/B Inlet Temperature High Setpoint (°F)	0	200	Rig Dependent
A/B Inlet Temperature Low Setpoint (°F)	0	200	Rig Dependent
A/B Inlet Pressure Data (PSI)	0	500	Rig Dependent
A/B Inlet Pressure High Setpoint (PSI)	0	500	Rig Dependent
A/B Inlet Pressure Low Setpoint (PSI)	0	500	Rig Dependent
Ratio Confirmation Data	nan.00 (zero)	25	Rig Dependent
Ratio Confirmation High Setpoint	0	25	Rig Dependent
Ratio Confirmation Low Setpoint	0	25	Rig Dependent

NOTE! The max Allowable Data Ranges are the software limits. Follow the actual values per the chemical manufacture's specifications.

6.2 GENERAL SCREEN INFORMATION

The screen has particular patterns to look out for when using the machine. A single widget encompasses a single control function. Each widget is outlined with a border. The border is colored to the respective chemical and operation.




Figure 8: Controls Widget Reference

The E-Stop and Active Alarm symbols will appear at the top right of your screen if you are receiving an alarm or your machines e-stop button is engaged. When there is an alarm active, a red “!” mark blinks above the bell. See Section 6.7, Page 41 for the events screen overview for further alarm information.



Figure 9: E-Stop



Figure 10: Active Alarm

6.2.1 COMMON WIDGET TRENDS

6.2.1.1 INPUT VALUES & VIEWING VALUES

Any value without a box around it is for viewing only. Any value with a box can be edited.

If the box is editable, there are two options to change the value. One is the +/- button option and the second is the keyboard option.

This pattern is followed throughout the entire machine.



Figure 11: +/- Buttons




Figure 12: Actual Values vs. Setpoints




Figure 13: Input Keyboard

6.2.1.2 BUTTON FUNCTIONS & VISUALS

Pushbuttons come in the color of their respective widget. Colors include Red, Blue, Purple, and Grey. Some include a LED light that turns green when active and white when inactive.



Figure 14: Inactive Button



Figure 15: Active Button

6.2.1.3 GAUGE FUNCTIONS & VISUALS

Gauges are for visuals only and cannot be edited. Data is represented in real time.




Figure 16: Exit Pressure Gauge




Figure 17: Drum Level Gauge

6.3 MACHINE SCREEN

This Machine Screen is where you control your pump, pressure balance, chemical temperatures, motor, and counters. You can also see exit pressure at a glance.




Figure 18: Machine Screen

6.3.1 A/B EXIT PRESSURE

This widget is a gauge that shows Exit pressure. Exit pressure can be monitored in real time. This is set by the pressure sensor on the side of the machine.



Figure 19: A Side Exit Pressure




Figure 20: B Side Exit Pressure

6.3.1.1 A/B SIDE HOSE HEATERS

This widget gives control of the Machines heaters. There's a real time temperature readout and a set point field. To use this, input the temperature you want the heater to be at and then press the enable button. These widget setpoints are retained on shutdown or until changed.




Figure 21: A Side Heater




Figure 22: Hose Heater




Figure 23: B Side Heater

6.3.1.2 COUNTDOWN COUNTER

This widget gives control of the machine pump countdown cycles. You can input a number of counts you want to run for. Once you hit set, the number appears above and proceeds to count down. When the counter hits 0 the pump will stop until the counter is reset. To reset the value, press the "Set" button and continue operation.




Figure 24: Countdown Counter

6.3.1.3 CYCLE COUNTER

This widget counts the number of cycles the pump has run. There is a reset button to reset the value in the cycle counter.




Figure 25: Cycle Counter

6.3.1.4 PUMP CONTROL

This widget lets you select the Pumps current mode. The Direction the pump is going is shown in neon green with an arrow in that direction. These widgets settings are retained on shutdown or until changed.

Retract: This lets you “Park” the pump to the A-side

Normal: This runs the pump back and forth between A and B-sides.

Off: This will turn the pump off.




Figure 26: Pump Control
Off




Figure 27: Pump Control
Retract




Figure 28: Pump Control
On w/ Retract On




Figure 29: Pump Control
On w/ Normal On

6.3.1.5 MOTOR ENABLE

This widget controls the motor. Pressing the power button turns the motor on. When the light is neon green, the motor is on.




Figure 30: Motor Enable

6.3.1.6 PRESSURE BALANCE CONTROL

This widget allows you to control the maximum difference between both sides based on what is input into the field. This widgets setpoints are retained on shutdown or until changed.

E.g., If you want the maximum difference between A side and B side to be 300PSI you would input 300 into the field. If the A side is 1400psi and B side is 1700psi. A Pressure Balance Alarm will trigger.




Figure 31: Pressure Balance Control

6.4 JOB SETUP SCREEN

The Job Setup screen is where you setup the high and low setpoints for the basic functions of the machine. Anything you would need to setup when installing and turning on the machine you can find here. You can set your drum levels and setpoints for inlet pressures and temperatures as well as ratio tolerances.




Figure 32: Job Setup Screen

6.4.1 A/B SIDE DRUM COUNTER

This widget shows how much of your chemical drum is left. You can input the Drums Max Capacity and the current level based on your own measurement. The chemical consumed is based on the flow sensor readings. This widgets setpoints are retained on shutdown or until changed. The reset Button resets the chemical consumed to 0. All units are measured in Gallons.





Figure 33: A Side Drum Counter Figure 34: B Side Drum Counter

6.4.2 A/B SIDE INLET TEMPERATURE

This widget allows you to see the inlet temperature for A and B side. The up arrow is the upper limit for the alarm setting. The Down arrow is the lower limit for the alarm setting. This widgets setpoints are retained on shutdown or until changed.




Figure 35: A Side Inlet Temperature




Figure 36: B Side Inlet Temperature

6.4.3 A/B SIDE INLET PRESSURE

This widget allows you to see the inlet Pressure for A and B side. The up arrow is the upper limit for the alarm setting. The Down arrow is the lower limit for the alarm setting. This widgets setpoints are retained on shutdown or until changed.




Figure 37: A Inlet Pressure




Figure 38: B Inlet Pressure

6.4.1 RATIO CONFIRMATION

This widget allows you to see what your current chemical ratio is. The alarm is enabled when the button is pressed. You can set the high and low limit for the ratio alarm. This widgets setpoints are retained on shutdown or until changed.

This widget is locked out for the basic user. Ownership or above can change the high and low setpoints. Enable can be used by all permission levels.




Figure 39: Ratio Confirmation

6.4.2 DRUM ALARM

This widget allows you to set a lower limit on chemical usage for both A and B sides. You can enable it by pressing the button once a value is set for both sides. Units are in Gallons. This widgets setpoints are retained on shutdown or until changed.




Figure 40: Low Drum Alarm

6.5 REPORT SCREENS

The Report Screen allows you to record and send data from your machine to you for tracking of chemical and machine operation. See Section 10 on Page 48 for more information on report generating and saving.




Figure 41: Reports Screen

6.5.1 RECORD ON LIGHT

The record on light has two stages. The first is when it is inactive the light is solid black. The second stage is when a report is in progress the button turns Red with black rings.



Figure 42: Recording Active Light




Figure 43: Recording Inactive Light

6.5.2 RECORD TIME

Recording time is displayed beneath the Record on Light. The time is updated every second and adds time accordingly.




Figure 44: Recording Report Time

6.5.3 MANUAL START REPORT RECORDING

This widget starts the recording for a report. Selecting an interval only effects the detailed report. Pressing close after selecting an interval starts the recording process.




Figure 45: Start Recording Button




Figure 46: Start Report Recording Window

6.5.4 MANUAL STOP REPORT RECORDING

This widget stops the recording process. Make sure all fields are filled out based on the job's description. Once the fields are filled out, press which report you would like generated. Once the report is generated press the close button.

NOTE! If you use the same information in the fields for a detailed and express report, the data will over write one another and corrupt the file.




Figure 47: Stop Recording Button




Figure 48: Stop Recording Window

6.5.1 EMAIL ADDRESS DIRECTORY

This widget lets you store 20 email addresses at a time.

Click on one of the “empty” fields. Once inside, a keyboard will appear. Input an email address. Once complete, press enter on the keyboard and press close to close the window.




Figure 49: Email Directory

6.5.2 SEND EMAIL

This widget lets you send an email of a report that was created. In the top left there is a light. If the light is a neon green color, the connection out of the machine is active. If it is white, there is no connection.

The select an email field uses the Email address Directory to pick an email. The select report field uses the log of reports that are in your machine to pick a report. The attach report button attaches the selected report to an email. This must be selected after both the email and report select dropdowns are chosen. The Send email button grabs the attached report and sends the report to the email selected.

To finish the process or exit at any time press the close button. See Section 10 on Page 48 for more information on report generating and saving.




Figure 50: Send Email Button




Figure 51: Send Email Window

6.5.3 REPORT SETTINGS

The Report Settings Widget lets you select the amount of time to delete files up to 30 days. When the Report folder becomes full the files get deleted on a file in file out basis.




Figure 52: Report Settings Button




Figure 53: Report Storage Window

6.5.4 USB DOWNLOAD

This widget lets you save any one of your reports or all of your reports to a USB stick. In the top left there is a light. If the light is a neon green color the USB is detected; if the light is white there is no USB detected.

The select report lets you choose an individual report that has already been created. The download selection button lets you download the individual file that was selected. The Download all button allows you to copy all reports created on your machine to a USB.

When the file is successfully moved over to the USB, the top bar will say "DOWNLOAD COMPLETE". The remove USB button allows you to safely remove the USB for ejection. The cancel button cancels any process you were in the process of using and closes the window. See Section 10 on Page 48 for more information on report generating and saving.



Figure 54: USB Download Button




Figure 55: USB Download Window

6.5.5 TEMPERATURE CONDITIONS

The Temperature Conditions screen allows for an active look at current values of temperature. Both in a graphical and chart-based format. The colors in the chart match the colors on the graph.




Figure 56: Reports Temperature Conditions

6.5.6 PRESSURE CONDITIONS

The Pressure Conditions screen allows for an active look at current values of Pressure. Both in a graphical and chart-based format. The colors in the chart match the colors on the graph.





Figure 57: Reports Pressure Conditions

6.5.7 **CHEMICAL USED**

The Chemical Used screen allows for an active look at current values of Pressure. Both in a graphical and chart-based format. The colors in the chart match the colors on the graph.



6.6 MAINTENANCE SCREEN.

The Maintenance Screen is used to aid in troubleshooting of the Premier. On this screen, you will see all of the inputs and outputs for the machine.




Figure 58: Report Maintenance Screen

6.6.1 ANALOG INPUTS

This widget shows the active raw data values of the Analog Inputs.

ANALOG INPUTS	
CH [01] A TRANSDUCER	0
CH [02] B TRANSDUCER	2
CH [03] A INLET	1
CH [03] R INLET	2
CH [05] OPEN	999
CH [06] OPEN	999
CH [07] OPEN	999
CH [08] OPEN	999

Figure 59: PLC Analog Inputs

6.6.1 DIGITAL INPUTS

This widget shows the active or inactive values of the Machines Inputs. If a light is on, the signal is coming back to the PLC. In Figure 60, the retract prox. sensor is active and the normal prox. sensor is inactive.




Figure 60: PLC Digital Inputs

6.6.2 DIGITAL OUTPUTS

This widget shows the active or inactive values of the Machines outputs. If a light is on, the signal is being output from the PLC to the corresponding device listed. In Figure 61, the E-stop is active so no outputs are turned on.




Figure 61: PLC Digital Outputs

6.6.3 THERMAL INPUTS 1

This widget shows the raw data for the heater and hose thermocouples.




Figure 62: PLC Thermal Inputs 1

6.6.4 THERMAL INPUTS 2

This widget shows the raw data for the A and B side Inlet Temperatures.




Figure 63: PLC Thermal Inputs 2

6.6.5 FLOW SENSOR INPUTS

This widget shows the raw data and current flow for the flow meters. The values being shown in Figure 64 (Currently 0.00), are measured in gallons/min. Flow stability is a confirmation that the sensors are functioning properly.




Figure 64: PLC Flow Sensor Inputs

6.6.6 MACHINE SETPOINT RESET

The machine setpoint reset allows you to set all machine setpoints to 0.



Figure 65: Machine Setpoint Reset Button




Figure 66: Machine Setpoint Reset Confirmation Window

6.6.7 MACHINE SERIAL NUMBER

The machine serial number widget shows the machines serial number. This number allows service to be able to keep track of each machine. This number cannot be changed.




Figure 67: Machine Serial Number

6.6.8 MACHINE LIFETIME CYCLE COUNT

Machine lifetime Cycle count allows you to see your machines lifetime cycle count. This cannot be changed.




Figure 68: Lifetime Cycle Count

6.6.9 SOFTWARE VERSION

This widget allows for help troubleshooting the particular code version on the machine and certain functions.



Figure 69: PLC Software Version

6.6.10 SUPPORT

The Support screen is for direct hyperlinks to knowledge and tech support for Premier machine customers.

The QR code on the left is responsible for a direct link to the manual at any time.

This QR code on the right is responsible for a direct link to the authorized list of distributors




Figure 70: Support Screen

6.7 EVENTS SCREEN

The Events screen is the main tool to track alarms and machine events. This screen is available at the top bar or in the drop down at the top right.

The screenshot shows the 'EVENTS' screen with a top bar containing an 'E-STOP' button, a bell icon, a gear icon, and the date/time '1/24/23 10:45 AM'. Below the bar, there are two main sections: 'Alarms History Table' and 'Audit View'.

Alarms History Table

From: 01/24/23 - 10:13:55
To: 01/24/23 - 10:43:55
Duration: 30 Mins
Refresh

Column Filter: Name

Timestamp	Name	State	Value	Description
01/24/23 - 10:24:02	TSU ALARM	Triggered Not Acked	1	

Backward Forward

Audit View

From: 01/24/23 - 10:13:55
To: 01/24/23 - 10:43:55
Duration: 30 Mins
Refresh

Column Filter: UserName

Record ID	Timestamp	UserName	Operation	Status	Information
245	01/24/23 - 10:24:53	User1	LOGIN	S_OK_NEED_PASWD_CHANGE	1
246	01/24/23 - 10:27:18	User1	CHANGE_PASSWORD	E_SIMILAR_PREV_PSWD	1
247	01/24/23 - 10:27:31	User1	CHANGE_PASSWORD	S_OK	1
248	01/24/23 - 10:27:53	User1	LOGOUT	S_OK	1

Backward Forward

Figure 71: Events Screen

6.7.1 EVENT LOG

The event log is used to track alarms. The Alarms can be tracked in time intervals of the following:

Duration
Intervals:

- 1 Min
- 5 Mins
- 10 Mins
- 30 Mins
- 1 Hour
- 2 Hours
- 4 Hours
- 8 Hours
- 12 Hours
- 1 Day

The screenshot shows the 'Alarms History Table' section of the interface. It includes filters for 'From' (01/24/23 - 10:13:55), 'To' (01/24/23 - 10:43:55), and 'Duration' (30 Mins), along with a 'Refresh' button. Below the filters is a 'Column Filter' set to 'Name'. The table displays one row of data: a timestamp of 01/24/23 - 10:24:02, the name 'TSU ALARM', the state 'Triggered Not Acked', a value of 1, and an empty description. Navigation buttons 'Backward' and 'Forward' are at the bottom.

Timestamp	Name	State	Value	Description
01/24/23 - 10:24:02	TSU ALARM	Triggered Not Acked	1	

Figure 72: Alarms History Table

6.7.2 AUDIT VIEW

The audit view is used to track user-based information. This includes login, logout, user deletion, user addition and user password changes.

Audit View

From: 01/24/23 - 10:13:55
To: 01/24/23 - 10:43:55

Duration: 30 Mins

Refresh

Column Filter:

UserName

Record ID	Timestamp	UserName	Operation	Status	Information
245	01/24/23 - 10:26:53	User1	LOGIN	S_OK_NEED_PASWD_CHANGE	1
246	01/24/23 - 10:27:18	User1	CHANGE_PASSWORD	E_SIMILAR_PREV_PSWD	1
247	01/24/23 - 10:27:31	User1	CHANGE_PASSWORD	S_OK	1
248	01/24/23 - 10:27:53	User1	LOGOUT	S_OK	1

Backward

Forward

Figure 73: Audit View Table

7 NETWORK CONNECTION

The network connection to the machine is provided by a Verizon 4G LTE Modem, no other service provider can be used. Both 4G and 5G SIM cards from Verizon work for this device. The network connection is provided by a Verizon 4G LTE Modem, no other service provider can be used. For the first year of your machine PMC covers the cost of this Verizon Service. The start date is based on your machines shipping date.

After the first year of service, you can take the SIM card that is in your machine and reactivate it with your Verizon representative. To do this you need the IMEI and the ICCID number that is on the SIM card itself. To find these two numbers you will need to open the top panel of your machine while it is off. The IMEI number will be located on the side of the router on a white label.



Figure 74: IMEI Number

To remove the SIM to get the number you need a paper clip/small pin to pop the tray out. The ICCID can be seen on the front of the SIM card.

NOTE! PMC is not responsible for any lapses in coverage based on network availability.

8 REMOTE ACCESS

8.1 CORVINA LOGIN

Go to the following website to log in to Corvina:

<https://us.corvinacloud.com/manage/access/login/>

See below for the basic structure for the Username and Password:

Email: TestUser/Test_Corporation

Password: ExamplePassword




Figure 75: Corvina Login Page

8.2 ACCESSING THE MACHINE

You can see which machines are connected by looking at the indicators on the right of each machine. If there is a red icon with an X the machine is not connected. If there is a green icon with a check the machine is connected.

▼ 99-0000	Test_Corporation		✖ offline No user connected
HMI	Test_Corporation	HMI	✖ offline No user connected
PLC	Test_Corporation	PLC	✖ offline No user connected
▼ 99-0000	PMC	Engineering Premier	✔ online No user connected
HMI	PMC	HMI	✔ online No user connected
plc	PMC	plc	✔ online No user connected

Figure 76: Corvina Active Machine Screen




Figure 77: Corvina Active Machine Icons

To access a machine, double click on that machine you want to connect to. A window will appear. In this window, you need to press on the VNC option. This lets you view and control the machine remotely. Anything you do remotely will affect the operation of the machine in real time.




Figure 78: Active Gateway VNC Connection

At the bottom of the “Active Gateway” screen, you will see “Gateway” and “Organization”.

Gateway: This is the machines serial number/name.

Organization: This is the distributors name of where the machine was purchased from.




Figure 79: Machine Gateway and Organization

9 FLOW METERS

The flow meters are connected directly to the PLC. They will turn on once the machine is powered up. All information received from the meter goes to the PLC over I/O link. All units of measurement are in gallons/minute.

9.1 CALIBRATION

NOTE! Follow the recommended procedure in the order shown.

CAUTION! For the best operation of the flow meter, ensure the pipes are filled with chemical by allowing the machine to run as normal for a few cycles.

1. On the flow sensor press the square button to get to the menu.
2. From the menu, navigate using the arrows to the settings menu and press the center select button to enter into the menu.
3. From the Settings menu, navigate to the “Useful Functions” menu.
4. Once in the “Useful Functions” menu, navigate to “[Flow] Origin Adj”
5. Press the center select button to use the function and select execute.
6. Your sensor should now be calibrated to the chemical you have in your system on that day.



Figure 80: Flow Meters
Step 2



Figure 81: Flow Meters
Step 3



Figure 82: Flow Meters
Step 4



Figure 83: Flow Meters
Step 5

NOTE! To get the most accurate measurements on your machine, it is recommended to do this at the beginning of each new job or material change.

10 JOB REPORTS

Job reports allow you to name and track job numbers and material usage across the entirety of a job. Machine set points and min./max. values will be displayed along with the option for time-based interval logging of these points. There are two types of reports; Express and Detailed.

10.1 EXPRESS REPORT

The express reports show only the essential information of the machine. This includes Job Number, Customer Name, Material Type, Lot Number, and corresponding data and graphs for Temperature, Pressure, and Chemical Conditions.

1. Each report has a header including Job Number, Material Type, Customer Name, and Lot Number.



Figure 84: Report Information Heading

2. The first part of the Temperature data section of the report is Temperature Condition Data. The charts will be in line graph form. This encompasses Inlet, Exit, and Hose Temperatures for the A and B sides.




Figure 85: Temperature Conditions Chart - Inlet & Exit




Figure 86: Temperature Conditions Chart – Hose

3. In the second part of the Temperature section of the report, you will see a chart filled with machine setpoints along with min./max. points of the recorded data. The length of the report is also shown.

	Inlet Temperature A (°F)	Inlet Temperature B (°F)	Exit Temperature A (°F)	Exit Temperature B (°F)	Hose Temperature (°F)
Upper Limit:	150.00	151.00			
Maximum:	72.00	75.00	122.00	126.00	108.00
Minimum:	71.00	71.00	79.00	81.00	77.00
Low Limit:	25.00	25.00			
Machine Time On:	11:11				

Figure 87: Temperature Condition Data

4. The first part of the Pressure data section in the report is the Pressure Condition Data. The charts will be in line graph form. This encompasses Inlet and Exit Pressure for the A and B sides.




Figure 88: Pressure Condition Chart - Inlet & Exit

5. In the second part of the Pressure section of the report, you will see a chart filled with the max./min. inlet and exit pressure points of the recorded data.

	Inlet Pressure A (PSI)	Inlet Pressure B (PSI)	Exit Pressure A (PSI)	Exit Pressure B (PSI)
Maximum:	91.00	77.00	642.00	648.00
Minimum:	62.00	57.00	155.00	81.00

Figure 89: Pressure Condition Data

6. The first part of the Chemical Condition data section in the report is the Chemical Data. The charts will be in line graph form. This encompasses the machines chemical ratio and the total chemical used for the A and B sides.




Figure 90: Chemical Condition Chart - Chemical Ratio & Chemical Used

7. In the second part of the Chemical section of the report, you will see a chart filled with the High setpoint, Low setpoint, and Ratio and Chemical Used points of the recorded data.

	Chemical Ratio:	Total Chemical Used A (Gal):
High Setpoint:	5.00	0.00
Setpoint:	1.07	Total Chemical Used B (Gal):
Low Setpoint:	1.00	0.00

Figure 91: Chemical Condition Data

10.2 DETAILED REPORT

The detailed report uses all the information in the express data and adds an interval-based log of all data points. After the Express data in the report is completed, the Detailed data is added to the end. You will see Temperature, Pressure, and Chemical data using the below data intervals.

Data Logging Intervals
3 Seconds
5 Seconds
10 Seconds
30 Seconds
1 Minutes
3 Minutes
5 Minutes

1. The Temperature Condition table logs Inlet and Exit temperature for the A and B sides as well as Hose temperature. This example uses a 10 second interval.

Temperature Condition Table

Timestamp	Inlet Temperature A (°F)	Inlet Temperature B (°F)	Exit Temperature A (°F)	Exit Temperature B	Hose Temperature
02/09/2023 - 01:57:50 PM	65.00	69.00	64.00	66.00	64.00
02/09/2023 - 01:58:00 PM	65.00	69.00	64.00	66.00	64.00
02/09/2023 - 01:58:10 PM	65.00	69.00	64.00	66.00	64.00
02/09/2023 - 01:58:20 PM	65.00	69.00	64.00	66.00	64.00
02/09/2023 - 01:58:30 PM	65.00	69.00	64.00	66.00	64.00
02/09/2023 - 01:58:40 PM	65.00	69.00	64.00	66.00	64.00
02/09/2023 - 01:58:50 PM	65.00	69.00	64.00	66.00	64.00
02/09/2023 - 01:59:00 PM	65.00	69.00	64.00	66.00	64.00
02/09/2023 - 02:07:50 PM	65.00	69.00	64.00	66.00	64.00
02/09/2023 - 02:08:00 PM	65.00	69.00	64.00	66.00	64.00
02/09/2023 - 02:08:10 PM	65.00	69.00	64.00	66.00	64.00
02/09/2023 - 02:08:20 PM	65.00	69.00	64.00	66.00	64.00

Figure 92: Temperature Condition Logged Data

2. The Pressure Condition table logs Inlet and Exit pressure for the A and B sides. Figure 93 uses a 10 second interval.

Pressure Condition Table

Timestamp	Inlet Pressure A (PSI)	Inlet Pressure B (PSI)	Exit Pressure A (PSI)	Exit Pressure B (PSI)
02/09/2023 - 01:57:50 PM	1.00	2.00	0.00	1.00
02/09/2023 - 01:58:00 PM	1.00	2.00	0.00	2.00
02/09/2023 - 01:58:10 PM	1.00	2.00	1.00	2.00
02/09/2023 - 01:58:20 PM	1.00	1.00	0.00	1.00
02/09/2023 - 01:58:30 PM	1.00	1.00	0.00	3.00
02/09/2023 - 01:58:40 PM	1.00	1.00	1.00	3.00
02/09/2023 - 01:58:50 PM	1.00	1.00	1.00	2.00
02/09/2023 - 01:59:00 PM	1.00	1.00	0.00	2.00
02/09/2023 - 02:07:50 PM	1.00	1.00	0.00	1.00
02/09/2023 - 02:08:00 PM	1.00	1.00	0.00	2.00
02/09/2023 - 02:08:10 PM	1.00	1.00	0.00	2.00
02/09/2023 - 02:08:20 PM	1.00	2.00	0.00	2.00

Figure 93: Pressure Condition Logged Data

3. The Chemical Condition table logs Chemical Ratio and Chemical Used for the A and B sides. Figure 94 uses a 1 minute interval.

Chemical Condition Table

Timestamp	Chemical Ratio	Total Chemical Used A	Total Chemical Used B
01/11/2023 - 02:14:00 PM	1.06	3.43	3.25
01/11/2023 - 02:15:00 PM	1.06	3.52	3.32
01/11/2023 - 02:16:00 PM	1.07	3.89	3.65

Figure 94: Chemical Conditions Logged Data

10.3 CAPTURING REPORTS

NOTE! When starting a new job or changing out materials, restart/start report recording.

1. To capture a report, press the “Manual Start Report Recording” button.
2. Select a report interval and press “Close”. Data is now being recorded.
3. When you are done recording press the “Manual stop Report Recording” button. When this opens up fill in all available information for your current job.
4. Once all information is filled generate a report of your choosing. You do this by pressing the “Generate Express Report” button or the “Generate Detailed Report” button.

NOTE! If you would like each type of report, you need to change the customer’s name to something different. If both reports have the same name, it will corrupt both files. Once the reports are created, you can send or move these files.




Figure 95: Start Report Flow Chart




Figure 96: Generate Report Flow Chart

10.4 SENDING REPORTS

NOTE! When emailing your report, you can only send one at a time. When saving to a USB device, you can save multiple at once.

10.4.1 EMAILING REPORTS

1. To send an email press the “Send Email” button.
2. Select an email address (See Section 0 Page 33) using the drop down and select the report you have selected.
3. Once both drop downs have the correct selection press the “Attach Report” button and press “Send Email”. A window will come up saying the email has been sent.

10.4.2 USB SAVING

1. To save files to a USB press the “USB Download” button. Select the report you would like to save to the USB.
2. Press “Download Selection” for a single report or “Download All” for all reports on the machine.
3. To remove the USB, press the “Remove USB” button next press the “Yes” button on the smaller window. Press OK to finish the process. It is now safe to remove your USB.





Figure 97: Emailing & Saving Report Flow Chart

11 INSTALLATION

WARNING! Use suitable protection and follow the recommendations in the Safety Information enclosed and provided by material suppliers when installing or working with the Proportioner.

CAUTION! Make sure the power cable is disconnected from the main power source before connecting to the Terminal Strip in the Console.

NOTE! To ensure the Premier Series Proportioner works correctly, the electrical supply must meet the specifications indicated on the Serial Number Placard affixed to the Electrical Console.



3 PHASE X 230 VOLT

Figure 98: Incoming Electrical Power Connection

1. Insert the main power cable by passing it through the wire stop at the bottom of the electrical console and connect as shown in the diagram above.
2. Fill the Hydraulic Reservoir with 16 gallons (61 Liters) of approved hydraulic fluid. See page 88 for hydraulic oil specifications.

NOTE! Do not fill the tank to maximum capacity; use the Visual Level Indicator on the tank to make sure the amount of hydraulic fluid is not more than 16 gal (61 L) or 80% of the tank's maximum capacity.

3. To check the level of the hydraulic fluid in the Hydraulic Pump Case, disconnect the Hydraulic Hose from the 90-degree fitting and remove Fitting from Hydraulic Case. Add fluid as required. Reattach Fitting and Hydraulic Hose. Turn the hydraulic pressure control knob counterclockwise until it stops, that is the lowest hydraulic pressure setting.




Figure 99: Installation

CAUTION! Ensure that the emergency stop is not engaged.

4. **Three Phase Proportioner Only:** Check the Electric Motor to ensure rotation is clockwise when viewing the end of the Electric Motor. A counterclockwise rotation indicates two of the incoming power leads need to be reversed.

CAUTION! Ensure Main Power Switch is OFF and incoming power/main disconnect is locked OFF before reversing power leads.

5. Recheck rotation before proceeding with Installation.
6. Fill the Lube Reservoir with PMC Pump Lube or suitable dilutants. It is not necessary to prime the system.

11.1 HEATED HOSE INSTALLATION

CAUTION! The material delivery Heated Hoses are color coded Red and Blue, allowing the user to recognize them. The Red corresponds to the Isocyanate (Iso, A) and the Blue to the Polyol (Poly, B). To avoid connection errors, the Coupling Connections of the Iso (A) and Poly (B) Heated Hoses are different sizes to ensure correct orientation.

NOTE! The material delivery Heated Hoses are capped at the ends to prevent absorbing moisture. Do not remove caps until the Heated Hoses are going to be installed on the Proportioner.

1. Lay out all the Heated Hose assemblies end to end aligning the Iso “A” (red) and Poly “B” (blue) and connect the respective Coupling Connections using the appropriately sized open-end wrench after ensuring Heated Hose assemblies lay flat.

CAUTION! Take care to not cross-thread or over-tighten the Coupling Connections. Thread seal tape or compound is not recommended for this tapered seat Coupling Connections.

2. Connect the material Heated Hoses to the outlets of the respective Heaters i.e., Iso (A) Heated Hose to the Iso (A) Heater and the Poly (B) Heated Hose to the Poly (B) Heater ensuring Heated Hose assemblies lay flat.
3. Connect Air Hose Coupling Connections.
4. Connect the Heated Hose power wires to the “Fast-Lock” Connector (Part# KT-00029A) coming from the Hose Heat Transformer as follows:
 - (a) Loosen the Socket Head Set Screw to allow insertion of the Heated Hose electrical wire Terminal.
 - (b) Insert the Terminal into the “Fast-Lock” Connector Body.
 - (c) Securely tighten the Socket Head Set Screw.
 - (d) Install electrical tape around Connector Body.

NOTE! A good practice is to add some dielectric grease (Permatex 67VR or equivalent) to the outside of the Terminal, where the electrical connection is made, prior to insertion.

5. Repeat the above steps to connect the “Fast-Lock” Connectors that you will find on all Heated Hose power wire.

CAUTION! Ensure the proper mechanical and electrical connections of the Heated Hoses are made to avoid possible material leakage and Hose heat problems.

6. It is recommended the TSU (Temperature Sensing Unit) be installed between the last section of Heated Hose and the Gun Whip. Carefully straighten the sensing wire, inserting it in the Iso (A) Heated Hose and tighten fluid fittings with appropriately sized open-end wrenches.

CAUTION! To protect the TSU sensor, you must pay special attention not to kink or excessively bend the Heated Hoses. Do not coil the Heated Hoses with a diameter of less than 4 feet (1.22 Meters).




Figure 100: Temperature Sensing Unit

Part# EL-51A-4

Replacement Sensor Part# EL-51A-2

CAUTION! Connecting the TSU between the first and second section of Heated Hose results in the TSU sensing the material temperature exiting the Heater and not the inside of the Heated Hose near the Spray Gun.

7. Ensure the Manual Valves are CLOSED and connect the Coupling Block to the Heated GunWhip.

CAUTION! Excessive force closing or opening the Manual Valves may result in damage to the Manual Valves and/or Coupling Block.

8. Connect the Transfer Pump/ Heated Hose Assemblies/Air Supply and Air Dryer systems as required. Review the Installation Instructions for each to ensure proper set-up and operation.
9. Install the Material Transfer Pumps as follows:

WARNING! If Transfer Pumps have been previously used, pay special attention to connect each Pump to its specific material. Inadvertently changing the Transfer Pumps will cause a chemical reaction rendering them useless.

NOTE! Placing a tape of the same color as of the Material Delivery Hoses (red for the Iso (A), blue for the Poly (B)) on each Transfer Pump would be a good method for minimizing errors in connection.

- (a) Make sure that the Inlet Valves on the Proportioner are closed.
- (b) Connect one end of the Polyol (B) Material Delivery Hose (3/4" thread) to the Proportioner Polyol (B) Inlet Valve and the other end to the Polyol (B) Transfer Pump.
- (c) Connect one end of the Iso (A) Material Delivery Hose (1/2" thread) to the Proportioner Iso (A) Inlet Valve and the other end to the Iso Transfer Pump.
- (d) Connect the air hose to the Transfer Pumps after ensuring each Transfer Pump Shut-Off Valve is CLOSED.

NOTE! To avoid errors in connection, the Coupling connections of the Iso (A) and Poly (B) Material Delivery Hoses are different sizes, making it difficult to swap connections.

10. Ground the Transfer Pump as recommend by the material supplier. The movement of product inside the Hoses can cause static electricity and produce electrical discharges.

- (a) Connect air to the airline coming off the first section of hose (90-110 psi, 6-8 bar)

11.2 HOSE HEAT TRANSFORMER

CAUTION! The Hose Heat circuit breaker needs to be off before working with the Hose Heat Transformer.

The Hose Heat Transformer offers the ability of connecting to different output voltages depending on the total length of the Heated Hose in use, maximizing the heating ability of the Heated Hose. The factory setting is 18 volts for use with 60 feet of Heated Hose. Before starting the Proportioner, ensure the setting matches the Heated Hose length installed. If Heated Hose sections are added or removed, the Tap setting should be changed to a setting which will limit the maximum amperage in the Heated Hose to 52 amps. The suggested settings are listed in the table below.

RECOMMENDED TAP SETTINGS		
Tap	Feet	Meters
120V	410	125
105V	360	109.7
90V	310	94.5
75V	260	79.2
60V	210	64
45V	160	48.8
30V	110	33.5
18V	60	18.3





Figure 101: Transformer Tap Settings

*120V transformers (shown above) allow for a maximum hose length of 410 ft (125 m).

12 START-UP

NOTE! Follow the recommended procedure in the order shown.

1. Check the lube fluid level and service as required.
2. Make sure the materials have been stored at the manufacturer's recommended temperature. Ask your material supplier for information (Safety Data Sheet) on the minimum storage temperature.
3. Y-Strainer screens should be checked routinely.
4. Connect air supply to the two Transfer Pumps and ensure Air Valves are in the fully OPEN position. OPEN both Proportioner Material Inlet Ball Valves.

CAUTION! Remove all Heated Hose sections from coiled storage and lay flat to eliminate heat build-up and possible Heated Hose failure.

5. Turn ON Main Power (See R on Page 20).
6. Turn ON Hose Heater (See 6.3.1.1 on Page 26) and confirm material set-point temperature as recommended by the material supplier or application conditions.

CAUTION! To avoid excessive pressure in the Proportioner, wait for the Hose Heater to reach its set-point temperature before continuing.

7. Turn ON each Primary Heater and confirm material set-point temperature as required by the material supplier or application conditions has been reached.
8. Turn ON Motor Power (See Section 0 on Page 27).
9. Set Pump Switch (See 6.3.1.4 on Page 27) to NORMAL. One of the Directional Indicator Lights will illuminate, indicating the Metering Pump direction, and the Metering Pump Shafts will begin to move.
10. Proceed with installation and start-up of the Spray Gun as per the gun manual.
11. Proceed to proportioner purging (Section 13 Page 63) before moving forward.

NOTE! The Material Pressure Gauges should be approximately equal and remain constant throughout the Metering Pump cycle. If not, refer to Trouble Shooting section.

13 PROPORTIONER PURGING

WARNING! Use suitable Personal Protection Equipment (PPE) and follow the recommendations in the Safety Information provided by product suppliers when installing or working with the unit.

WARNING! Do not turn the Temperature Controllers ON until the Proportioner purging procedure is complete and the Primary Heaters and Heated Hoses are filled with material.

NOTE! Before using the Proportioner it is necessary to purge the entire system, including Heated Hoses, of mineral oil left over from Quality Control testing and air. The following procedure is also followed to purge air entrapped by running out of material in the supply Drum/Reservoirs resulting in a significant indicated material pressure imbalance as indicated by the Pressure Gauges and sprayed material.

1. Ensure the following before proceeding:
 - a. Air supply to Transfer Pumps is 90 - 110 psi (6 - 8 bar).
 - b. Proportioner inlet ball valves are CLOSED.
 - c. All connections are tight.
 - d. Material should be stored to the material suppliers recommended temperatures.
 - e. Spray gun coupling block is installed and manual valves are closed.
2. Slowly OPEN the Poly (B) Transfer Pump Air Shut-Off Valve allowing Pump to cycle slowly as it fills the Material Delivery Hose to the Proportioner. Check for leaks.
3. OPEN Poly (B) Coupling Block Manual Valve over a waste container.
4. Slowly OPEN Proportioner Poly (B) Inlet Valve allowing Transfer Pump to move material through the system. When all spitting of air stops and all traces of mineral oil have disappeared, CLOSE Poly (B) Coupling Block Manual Valve. Clean Coupling Block.
5. Repeat steps 2 to 4 for Iso (A) side.

CAUTION! Properly dispose of all waste chemicals in accordance with all applicable local, state, and federal codes. DO NOT turn on the Auto Countdown Widget (Section 6.3.1.2 Page 26) or the Pressure Balance Control Widget (Section 6.3.1.6 Page 27) until after full setup is complete.

6. Turn Hydraulic Pressure Control (See N on Page 19) fully COUNTERCLOCKWISE.
7. Turn ON Main Power (See R on Page 20). Green pilot will light.
8. Turn ON Motor Power (See Section 0 on Page 27). Widget will light.
9. Set Pump switch (See 6.3.1.4 on Page 27) to NORMAL. Turn Hydraulic Pressure Control CLOCKWISE increasing material pressure to 400 psi (28 bar). Both Material Pressure Gauges (See E and F on Page 19) should approximately read the same. Check all Heated Hose Coupling connections for leakage.
10. Check all TSU connections for leaks.
11. Bundle all Heated Hose Connections ensuring that there are NO kinks in the TSU Cable or Air Hose. Wrap with Electrical Tape to securely hold all components in place and minimize places for bundle to snag onto job site protrusions.

14 MACHINE STOP

14.1 IDLE

Follow the procedure below for temporary shutdowns, such as **lunch breaks**:

1. Set Pump Switch (See 6.3.1.4 on Page 27) to the OFF position.
2. Turn both “A” and “B” Heaters OFF. Hose Heater should remain ON. Never leave Proportioner ON if unattended.
3. CLOSE Spray Gun Manual Valves.

CAUTION! Excessive force opening or closing the Manual Valves may result in damage to the Manual Valves and/or Coupling Block.

14.2 SHUT DOWN

Follow the procedure below for shutdowns when work is **stopped for the day**:

1. Set Pump Switch (See 6.3.1.4 on Page 27) to the RETRACT position.
2. Spray off the application surface until Material Pressure Gauges (See Items E & F on page 19) read approximately 400psi.

CAUTION! To avoid possible Proportioning Pump Seal weepage, and moisture vapor drive into the Heated Hoses, the system pressure should not be reduced to zero. It is recommended to lower the system pressure to a minimum of 400 psi (28 bar).

3. CLOSE the Spray Gun Coupling Block Manual Valves.
4. Turn OFF Motor Power (See Section 0 on Page 27).
5. Turn OFF the A and B Heaters and Hose Heater (See 6.3.1.1 on Page 26).
6. If recording data, stop recording and save report (See 10.4 On Page 54).
7. Turn OFF the Main Power (See R on Page 20).
8. Disconnect the air supply to the two Transfer Pumps and CLOSE the Proportioner Material Inlet Valves.

CAUTION! Excessive force opening or closing the Manual Valves may result in damage to the Manual Valves and/or Coupling Block.

15 TROUBLESHOOTING

This Premier Series Proportioner has been designed and built to withstand severe working conditions with a high degree of reliability, provided that it is used in a suitable application by a properly trained operator. This chapter contains information on possible faults that may interrupt the operation of the Premier Series Proportioner. The information provided will serve as a guideline to detect and resolve problems. In any case, feel free to contact your authorized PMC distributor, where a qualified technician will advise you.


WARNING! Only qualified personnel should perform troubleshooting; unqualified personnel may cause damage to the unit and put the operator at risk.

	<i>To prevent possible injury caused by incorrect handling of the raw materials and solvents used in the process, carefully read the Safety Data Sheet (SDS) provided by your supplier. Deal with the waste caused according to current regulations.</i>
	<i>To avoid damage caused by the impact of pressurized fluids, do not open any connection, or perform maintenance work on components subject to pressure until the pressure has been completely eliminated.</i>
	<i>Use suitable protection when operating, maintaining or being present in the area where the equipment is functioning. This includes, but is not limited to, the use of protective goggles, gloves, shoes, and safety clothing and breathing equipment.</i>
	<i>The equipment includes components that reach high temperatures and can cause burns. Hot parts of the equipment must not be handled or touched until they have cooled completely.</i>
	<i>To prevent serious injury through crushing or amputation, do not work with the equipment without the safety guards installed on the moving parts. Make sure that all the safety guards are correctly reinstalled at the end of the repair or maintenance work of the equipment.</i>

WARNING! Before correcting any kind of defect, make sure the Main Power Switch is OFF and incoming power is locked OFF. NEVER access the inside of the Control Panel with the Proportioner power supply ON.

15.1 HEATERS

WARNING! Only qualified personnel should perform troubleshooting; unqualified personnel may cause damage to the unit, personnel, or property and put the operator at risk. The Heaters are components that reach high temperatures; you must wait until they cool before handling.



NOTE! The Thermal Limit Switch is a safety switch in contact with the Heater Body. If the surface temperature exceeds 220°F (109°C) the Limit Switch will shut off the Heater power. The Limit Switch will not reset until the temperature in the Heater is below 190°F (88°C). The system is designed that in case of an over temperature, a contactor located in the console will open and disable power to both Heaters and the Hose.

Frequent Heater Problems

Primary heater does not heat and the display on the PLC shows ambient temperature.	Page 68
Primary heater does not heat and the display on the PLC shows an error message.	Page 69
Primary heater controller shows excessive temperature, and the circuit has turned off.	Page 69
Primary heater Temperature drops excessively while spraying.	Page 69

Follow the recommended procedure in the indicated order to solve the problem and avoid unnecessary repairs. Make sure all Switches are in the correct position and Indicator Lights ON before determining the existence of a fault.

- **Problem:** Primary heater does not heat and the display on the PLC shows ambient temperature.

Solutions:

1. Check that the light on the heater widget is lit.

If the light is on, move to the next step.

2. Check the heater breaker in the main console. If tripped, reset the breaker. If it continues to trip, wrap a Clamp style multimeter around one of the wires coming off the breaker. If the Amperage reading does not exceed the rating of the breaker, the breaker needs to be replaced. If the breaker draws more than it is rated for (32A), the most likely cause is that one or more of the fire rods located in the heater are shorted.

If the breaker is not tripped, move on to the next step.

3. Open the console top and locate the solid-state relays for the heaters, looking over the console top from the front of the machine. There are two relays to the left bottom of the console, the one to the far left is for the "A" heater and the one to the right is for the "B" heater. With the heater on, look to see if an LED light is lit on the relay and heater widget (Section 6.4.2 Page 29).

If there is no LED light on the solid-state relay, move to the next step.

4. With a DC voltmeter read across position A1 and A2 on the solid-state relay (smaller wires) if you have a reading of 23-24 volts DC and the AC reading across L1 and L2 (Heavy wires) reads 208-230 volts AC replace the solid-state relay. With 23-24 volts DC at A1 and A2 the proper reading should be 1 volt AC across L1 and L2. A defective over temperature switch will open a contactor disabling both Heaters and the Hose.

If there is no DC voltage to the relay, move to the next step.

5. Check the M1 contactor to ensure it is activated. If not, inspect the contactor for failure.

If the M1 contactor is activated, move to the next step.

-
- **Problem:** Primary heater does not heat and the display on the HMI shows an error message.

Solutions:

1. Remove the heater cover and check that the thermocouple wires are secure to the harness going up to the controller.

If there are no loose connections replace the heater thermocouple.

-
- **Problem:** Primary heater widget shows excessive temperature, and the circuit has turned off.

CAUTION! The heater must be allowed to cool down before continuing.

Solutions:

1. Set the widget set point at least 20 degrees lower than the temperature shown. Briefly turn on the heater and look for the LED light on the solid-state relay and the heater widget to be on.

If the light is on the widget and not on the relay, replace the relay

If the light is on the relay but not the screen, contact your authorized PMC distributor for further assistance

-
- **Problem:** Primary heater Temperature drops excessively while spraying.

Solutions:

1. Temperature of the chemical in the containers is too cold.
2. Exceeding the flow rate specification of the machine. Use a smaller mixing chamber to reduce flow.
3. Disconnect power to the machine. One or more of the fire rods in the heater have malfunctioned. Remove the heater cover and disconnect the wires to measure the resistance across each rod. Installing a smaller mixing chamber in the gun may allow you to spray until a new rod(s) is installed.

CAUTION! If the rod that is used in conjunction with the thermocouple is defective, do not operate the heater until the rod is replaced.

Individual Ohm Measurement

1500 WATT	31 OHMS
-----------	---------

15.2 HYDRAULIC DRIVE SYSTEM

Frequent Hydraulic Drive System Problems

Hydraulic Pump does not develop pressure and the electric motor is not running.	Page 70
Hydraulic Pump does not develop pressure.	Page 71
Low or zero hydraulic pressure with unusual Hydraulic Pump noises.	Page 71


Follow the recommended procedure in the indicated order to solve the problem and avoid unnecessary repairs. Make sure all Switches are in the correct position and Indicator Lights ON before determining the existence of a fault.

WARNING! Only qualified personnel should perform troubleshooting; unqualified personnel may cause damage to the unit, personnel, or property and put the operator at risk. The Heaters are components that reach high temperatures; you must wait until they cool before handling.

CAUTION! Excessive force opening or closing the Manual Valves may result in damage to the Manual Valves and/or Coupling Block.

-
- **Problem:** Hydraulic Pump does not develop pressure and the electric motor is not running.
Solutions:

Motor Contactor Overload - The Electric Motor is protected from excessive current by an Overload Switch. After allowing the Motor to cool, open the Control Panel and reset Motor Contactor Overload.



-
- **Problem:** Hydraulic Pump does not develop pressure.
Solutions:

NOTE! Hydraulic pressure is not generated if the Motor Power Switch (See Section 0 on Page 27) is OFF or the Pump Switch (See 6.3.1.4 on Page 27) is in the OFF position.

Hydraulic Power Package - With the Pump Switch in the NORMAL position, the failure of the Hydraulic Pump to develop pressure is loss of pump suction (prime). To ensure positive prime, check the following:

- a. Motor Rotation.
- b. Hydraulic Reservoir is filled to the correct level.
- c. Hydraulic Pump Case is filled with the proper hydraulic fluid.
- d. Loose Inlet Plumbing: Check that all inlet plumbing to Hydraulic Pump is tight ensuring no air leakage into the hydraulic system.

-
- **Problem:** Low or zero hydraulic pressure with unusual Hydraulic Pump noises.
Solutions:

1. The use of an incorrect hydraulic fluid can result in unusual noises from the pump, excessive wear, and moisture absorption. Ensure the hydraulic oil used is from the list on page 53. In addition, continuous excessive hydraulic oil temperature as well as failure to change the hydraulic oil on a yearly basis will cause the oil to fail and result in excessive Hydraulic Pump wear and unusual noises.
2. Loose Inlet Plumbing: Check that all inlet plumbing to Hydraulic Pump is tight, ensuring no air leakage into the hydraulic system.

15.3 METERING PUMP LINE




Figure 102: Metering Pump-Line

Frequent Pump-Line Problems

Metering pumps do not change direction and the pressures on both of chemical gauges are lower than normal.	Page 72
Cavitation.	Page 75
Pressure Loss: Discharge/Inlet Ball.	Page 75

Follow the recommended procedure in the indicated order to solve the problem and avoid unnecessary repairs. Make sure all Switches are in the correct position and Indicator Lights ON before determining the existence of a fault.

- **Problem:** Metering pumps do not change direction and the pressures on both of chemical gauges are lower than normal.

Solutions:

1. The Metering Pump Line has a Reversing Plate which actuates two Proximity Switches (EL-153), one at each end of the stroke. The Prox. Switches in turn actuate the appropriate Directional Valve Solenoid (HI-05003). Failure to make contact with either Prox. Switch may be caused by:
 - a. Deformation of the Reversing Plate.
 - b. Foreign material preventing the Reversing Plate from contacting the Prox. Switches.
2. Passing of the Reversing Plate beyond the Prox. Switch may be caused by:
 - a. Failure of the Prox. Switch and related components on the side of the over-run.
 - b. Failure of a component of the Directional Valve.
 - c. Mounting Plate (PU-07006) and/or Prox. Switch is out of adjustment.

NOTE! IF THE DIRECTIONAL INDICATOR ARROW (See 6.3.1.4 on Page 27) IS ON CHECK THE REVERSING VALVE COIL ON THE SIDE THAT THE ARROW IS ON. IF YOU HAVE 24 VOLTS DC AT THE PLUG, CHECK THE OHM'S RESISTANCE OF THE COIL, IT SHOULD READ APPROXIMATELY 19 OHMS, IF NOT REPLACE THE DIRECTIONAL VALVE. IF THE DIRECTIONAL LIGHT IS OFF PROCEED BELOW.




NOTE! BEFORE TROUBLESHOOTING, THE REVERSING PLATE MUST BE MOVED AWAY FROM THE SWITCH.

- d. Bleed down the chemical pressures.
- e. Ensure Pump Switch (See 6.3.1.4 on Page 27) is **OFF**.
- f. Turn on the Motor Power (See Section 0 on Page 27).
- g. Go to the Directional Valve and locate the Actuation Coils. Located in the middle of each coil is a small round tab that can be pushed in to manually shift the spool to move the pumps. If the Reversing plate is all the way to the left push in on the right-side coil. If it is all the way to the right side, push in on the left side coil.

WARNING! THE MOTOR MUST BE OFF AND THE PUMP SWITCH IN THE NORMAL POSITION.

- h. Take a small screwdriver or a thin piece of metal and move it across the front of each Prox. switch. A red light on the back of the switch should illuminate. If not, replace the switch that does not light.
- i. If the Prox. switches light up, turn off all power and check for continuity on both over pressure switches, pin 1 and 2.

3. Safety Pressure Switch - Each Metering Pump has a Safety Pressure Switch set to 2,250 psi. for # 120 pumps. When the material system reaches this pressure, the PLC will remove power from the Directional Valve and Directional Indicators (See 6.3.1.4 on Page 27). Lack of Directional Indicators along with high pressure indicated on one or both of the material Pressure Gauges (E, F, Section 5) is an indication of an over-pressure condition. The Safety Pressure Switches are a momentary design; when the pressure bleeds off the Metering Pump Line will resume normal operation. However, the cause of the over-pressure should be determined and corrected. The most common causes are:
- Cavitations of the Metering Pump on the **low**-pressure side causing high pressure on the opposite side.
 - A restriction in the Spray Gun on the **high**-pressure side.
4. Pressure/Material Imbalance - Troubleshooting this problem requires the applicator to:
- Know what the NORMAL spray pressures are for the application in progress.
 - Determine what material is NOT exiting the Mixing Chamber.
 - Read the Pressure Gauge on the problem side and interpret the reading.

Material Condition	"A" GAUGE	"B" GAUGE
NORMAL		
LACK OF ISO (A)		
LACK OF POLY (B)		
RESTRICTION OF ISO (A)		
RESTRICTION OF POLY (B)		

-
- **Problem:** Cavitation.

Solutions:

1. Cavitations occur when the Metering Pump (B or C, Section 5) requires a larger volume of material than the supply system (Transfer Pump) can furnish. This creates a “void” of material in the Metering Pump. The most common causes of cavitations are:
 - a. Material temperature too low causing increased material viscosity resulting in the inability of the Transfer Pump to maintain sufficient supply to the Metering Pump. This is most common with today’s blowing agents. Ensure the material temperature in the drums is no lower than the material suppliers’ recommendation.
 - b. Failure to vent the material drum while drawing material out with the Transfer Pump causes a vacuum and cavitations in the Transfer Pump. Ensure the drum is vented to the atmosphere or a Desiccated Air Dyer Kit is installed as recommended by the material supplier.
 - c. Insufficient air volume for Transfer Pump or a partially closed Transfer Pump Air Valve will limit the ability of the Transfer Pump to operate at its maximum capability.
 - d. Inlet Material Screen (Q, Section 5) obstructed (See Section 16.2 Page 81).
 - e. Metering Pump Inlet Ball does not seat properly allowing material to flow back into the Material Delivery Hose when the Metering Pump is on the “Discharge” stroke. This causes the volume of material on that Metering Pump to be less on the discharge stroke resulting in intermittent off-ratio material and Pressure Gauge fluctuation.

-
- **Problem:** Pressure Loss: Discharge/Inlet Ball.

Solutions:

1. Simultaneous observation of the material Pressure Gauge (**Error! Reference source not found.**, Page **Error! Bookmark not defined.** in Section 5) and Directional Indicator Arrow (Page 27, Section 6.3.1.4) is necessary to determine which direction the Metering Pump fails to maintain pressure. Refer to the chart to determine problem:

	Left Arrow ON	Right Arrow ON
Iso Pressure Gauge FALLS	Iso Inlet Ball does not seat properly	Iso Discharge Ball does not seat properly
Poly Pressure Gauge FALLS	Poly Discharge Ball does not seat properly	Poly Inlet Ball does not seat properly

In most cases the cause of a leaking Inlet/Discharge Ball is foreign material preventing the Ball from seating properly. If the above steps do not resolve the problem, replace the appropriate Ball. For service see MAINTENANCE: METERING PUMP-LINE (Page 84).

15.4 HOSE HEATING

WARNING! Before correcting any kind of defect, make sure the Main Power Switch is OFF and incoming power is locked OFF. NEVER access the inside of the Control Panel with the Proportioner power supply ON. The Heated Hose are components which reach high temperatures; you must wait until they have cooled before handling.

CAUTION! Excessive force opening or closing the Manual Valves may result in damage to the Manual Valves and/or Coupling Block.

Hose Heating Problems

Heated Hose does not heat and the display on the screen shows ambient temperature.	Page 76
Hose does not heat and the display on the screen shows an error message.	Page 77
Hose will heat but does not come up to set temperature.	Page 78

Follow the recommended procedure in the indicated order to solve the problem and avoid unnecessary repairs. Make sure all Switches are in the correct position and Indicator Lights ON before determining the existence of a fault.

-
- **Problem:** Heated Hose does not heat and the display on the screen shows ambient temperature.
Solutions:

1. Check that the button is lit when the heater is turned on.
If the light is on, move on to the next step.
If the light is off, contact your authorized PMC distributor for further assistance.
2. Check the Hose Heat breaker in the main console and reset the breaker. If it continues to trip, wrap a clamp style multimeter around one of the wires coming off the breaker. If it does not draw more than the rated value of the breaker, the breaker needs to be replaced.
If the breaker is not tripped, move on to the next step.
3. Check the circuit breaker mounted on the transformer and reset the breaker. If it continues to trip, wrap a clamp style multimeter around one of the wires from the transformer going to the heated hose. If it does not draw more than the rated value of the breaker, the tap setting on the hose transformer needs to be lowered.
If the Amp Draw is less than the rated value, move on to the next step.
4. Check that the tap setting on the transformer is set for the proper hose length.
If it is set correctly, move to the next step.

5. To check the secondary side of the transformer, you must take an AC volt reading across the two leads coming out of the transformer that are connected to the "A" and "B" hose leads. If you are reading voltage (your volt reading will vary depending on what tap setting is used), most likely the problem is in the heated hose. Either a connector has come loose or there is a broken wire.
6. Because the gun whip takes the most abuse, it is most likely the whip that has failed. Disconnect the crossover wires on the machine end of the whip hose and connect the two wires together coming off the 50' section. Turn on the hose heat and see if the hose heat circuit is operating; if so, replace the whip. To take a continuity reading through the heated hose, one of the leads from the transformer to the "A" or "B" heated hose must be disconnected.

If no voltage is coming out of the transformer to the heated hose, move onto the next step.

7. Open the front side of the transformer cabin (where the transformer is located) and locate the solid-state relay for the hose circuit (EL-35). With the hose turned on and the LED light illuminated on the relay, take a voltmeter (set on DC) and measure across position A1 and A2; your reading should be 24 volts. Then take an AC volts measurement across position L1 and L2 (heavy wires). With the relay functioning properly you should have a 1-volt Reading. If the Reading is 18 to 90 volts AC, the relay has malfunctioned and needs to be replaced. If the AC Reading across L1 and L2 is .025 volts check the over temperature switches in the heaters. A defective over temperature switch will open a contactor disabling both Heaters and the Hose.

If there is no light on the solid-state relay, move to the next step.

8. Using a DC voltmeter, measure across pin OD5121-A2(-) on the PLC of the 107(+) terminal block. This is the output of the controller and sends power to the solid-state relay. Your reading will be **23-24 VDC**. If there is no voltage, check to make sure that the set temperature of the controller is above ambient temperature.

If there is no DC voltage to the relay, Contact your authorized PMC distributor for further assistance.

-
- **Problem:** Hose does not heat and the display on the screen shows an error message "0".
Solutions:

1. Check position TS3101-C7 (Purple Wire) and TS3101-D7 (Red Wire) on the PLC's temperature card for loose wires.

If the wires are tight, move to the next step.

WARNING! Make sure to turn the machine off before moving forward.

2. Remove the transformer cover and check that the thermocouple wires are secure to the harness going up to the controller. If there are no loose connections, disconnect the wire from the TSU and connect it directly to the thermocouple harness coming out of the hose transformer.

If the machine still shows the error, replace the hose thermocouple. If the error goes away and temperature is now shown on the screen, then all the TSU harnesses from the TSU to the transformer need to be checked for loose connectors or one or more of the harnesses defective.

- **Problem:** Hose will heat but does not come up to set temperature.

Solutions:

1. Check the tap setting on the transformer to ensure that the correct position has been selected for the length of hose being used. Depending on the machines incoming voltage, you may have to move the tap setting higher (up one).

CAUTION! Do not exceed the amperage rating (63A) of the transformer hose breaker.

WARNING! Before correcting any kind of defect, make sure the Main Power Switch is OFF and incoming power is locked OFF. NEVER access the inside of the Control Panel with the Proportioner power supply ON.

15.5 PRESSURE BALANCE CONTROL

If the Pressure Balance Control is not working properly, Contact your authorized PMC distributor for further assistance.

16 MAINTENANCE

To achieve maximum output from the Premier Series Proportioner, a daily or regular maintenanceschedule is required.

	<i>To prevent possible injury caused by incorrect handling of the raw materials and solvents used in the process, carefully read the Safety Data Sheet (SDS) provided by your supplier. Deal with the waste caused according to current regulations.</i>
	<i>To avoid damage caused by the impact of pressurized fluids, do not open any connection, or perform maintenance work on components subject to pressure until the pressure has been completely eliminated.</i>
	<i>Use suitable protection when operating, maintaining or being present in the area where the equipment is functioning. This includes, but is not limited to, the use of protective goggles, gloves, shoes, and safety clothing and breathing equipment.</i>
	<i>The equipment includes components that reach high temperaturesand can cause burns. Hot parts of the equipment must not be handled or touched until they have cooled completely.</i>
	<i>To prevent serious injury through crushing or amputation, do not work with the equipment without the safety guards installed on the moving parts. Make sure that all the safety guards are correctly reinstalled at the end of the repair or maintenance work of the equipment.</i>

CAUTION! All repairs performed by unqualified personnel or the use of parts other than supplied by PMC may cause damage to the unit and put the operator at risk.



PMC Equipment Maintenance Schedule

80

16.2 INLET MATERIAL SCREENS

Inspection of the Inlet Material Screens on a daily basis is no longer necessary as long as the following conditions are met.

1. Material drums are stored within the recommended material storage temperature range and drums are not opened prior to installing the Proportioner Material Transfer Pumps.
2. Desiccant air dryers are used to dry replacement air as material is removed from the drums to the Proportioner.
3. Consolidation of old material into a common drum for use is minimized, especially the Iso (A).

If the above conditions are met, inspection of the Inlet Material Screens may be done on a **bi-weekly** basis.

NOTE! Inspect and clean Inlet Material Screens before Proportioner start-up. They should not be cleaned after the days' operation as the Proportioner should be purged (see page 63) immediately after inspection and cleaning. This is to reduce the risk of moisture contamination, contamination through the reaction with the solvent used in the cleaning operation, and cross-over at the Spray Gun due to air entrapment.

CAUTION! Make sure the Main Power Switch is OFF and incoming power is locked OFF.




Figure 103: Inlet Strainer Components

1. CLOSE the Poly (B) Proportioner Inlet Valve.
2. Place a suitable container under the Material Inlet Strainer to collect the residual material. Carefully loosen the Strainer Nut to drain material into the container.
3. Completely unscrew the Strainer Nut.
4. Remove the Seal, Spring and Screen and clean them with a suitable solvent. Dry the parts and ensure the Screen is not obstructed. Replace the Screen if more than 20% of the Screen surface is obstructed by residue.
5. Reinstall the Screen, Spring and Seal. Grease the threads and screw on the Strainer Nut.

6. OPEN the Poly (B) Proportioner Inlet Valve, pressurize the Material Transfer Pump, check for leaks, and wipe Y-strainer clean.
7. Repeat above for the Iso (A) side.
8. Proceed with Proportioner Purging operation (See page 63).

16.3 ISO LUBRICATION SYSTEM

DAILY: Check the condition of the PMC Lube Oil in the Iso Lube Reservoir. Replace the PMC Lube Oil if you see significant changes in the color or signs of solidification. Ensure inside of Reservoir is wiped clean.




Figure 104: ISO Lubrication System

To replace the Lube Oil, proceed as follows:

4. Remove the Lube Reservoir from its support, unscrew the Lid and remove the Check Valve from the Suction Hose.
5. Empty the contaminated Lube Oil in a waste container and refit the Check Valve in the Suction Hose.

NOTE! Valve is directional.

6. Clean the Reservoir, refill with Lube Oil, and screw on the Lid and place the Reservoir in its support.

NOTE! The system is auto-suction and does not need priming.

16.4 HYDRAULIC DRIVE SYSTEM

WARNING! Before performing any maintenance, make sure the Main Power Switch is OFF and incoming power is locked OFF. The Hydraulic Unit is a component that works under pressure. Do not open any connection or carry out maintenance on components subject to pressure until all pressure has been bled to zero.

The hydraulic unit should be serviced yearly:

1. Completely drain the Tank of hydraulic fluid.
2. Clean the Tank Top to prevent foreign material from falling into the Tank when the Cover is removed.
3. Unscrew the Suction Pipe from its connection with the Hydraulic Pump.
4. Remove the Cover and Suction Pipe from the Hydraulic Tank. Take care not to damage Tank Cover Gasket.
5. Inspect the bottom of the Tank for sediment and clean as required. Clean the Suction Pipe and its connections.
6. Fill the Tank with 16 gal (61 L) of approved hydraulic fluid (See page 88 for recommendations).
7. Insert the Suction Pipe into the Tank Cover and install the Cover. Again, take care not to damage Tank Cover Gasket. Connect the Suction Pipe securely to the Hydraulic Pump.
8. Ensure the Hydraulic Pump Case is full of fluid and proceed with the normal operation.

16.5 METERING PUMP-LINE

WARNING! Before performing any maintenance, make sure the Main Power Switch is OFF and incoming power is locked OFF. Allow material temperature to cool below 80°F and bleed all material pressure to zero.

Weekly: When the Proportioning Pumps are functioning properly it is not unusual for a small amount of Poly (B) material to appear on the Pump Shaft. This material should be wiped away, so dirt does not accumulate on the Pump Shaft and the Pump Shaft Packings are not damaged.

Yearly or as required: It is not unusual for those who use the Premier Series Proportioner on a regular basis to rebuild the Proportioning Pumps on a yearly basis and service the Hydraulic Drive System (See page 83) at the same time, while the Proportioner is out of service.

16.6 PUMP BASE SERVICE

1. The Metering Pump Line has a Reversing Plate which actuates two Proximity Switches (EL-153), one at each end of the stroke. The Prox. Switches in turn actuate the appropriate Directional Valve Solenoid (HI-05003). Failure to make contact with either Prox. Switch may be caused by:
 - a. Deformation of the Reversing Plate.
2. CLOSE appropriate proportioner inlet material supply valve and remove airline from transfer pump.
3. Ensure all material pressure in the Proportioner system is zero and remove appropriate Retainer Nut.
4. For Inlet Ball
 - a. Remove Inlet Ball with a magnet (DO NOT use any sharp object), clean Ball and Ball Seat, and inspect for foreign material and any damage on the Inlet Ball.
 - b. Using supplied Ball Seat Tool (TL-02), check for proper Ball Seat Gasket compression. Snug Seat up to 1/4 turn maximum 110ft-lbs (149Nm).
5. For Discharge Ball:
 - a. Remove Cage and Spring.
 - b. Remove Discharge Ball with a magnet (DO NOT use any sharp object), clean Ball and Ball Seat, and inspect for foreign material and any damage on the Discharge Ball.
 - c. Using supplied Ball Seat Tool (TL-02), check for proper Ball Seat Gasket compression. Snug Seat up to 1/4 turn maximum 30ft-lbs (41Nm).

16.7 PUMP SEAL REPLACEMENT

NOTE! Refer to Parts Identification for reference.

1. When the Iso (A) Proportioning Pump Cylinder is disassembled for service, all parts included in the Pump Rebuild Kit (KT-07000, KT-07002, KT-07004, KT-07006) should be replaced.
2. When the Poly (B) Proportioning Pump Cylinder is disassembled for service, all parts included in the Pump Rebuild Kit (KT-07001, KT-07003, KT-07005, KT-07007) should be replaced.
3. When assembling Proportioning Pump lubricate all Seals, Piston Rod and Pump Cylinder with #1 Lithium Grease to assist in assembly and minimize Seal damage during re-assembly.
4. When the Pump Base is disassembled for service, all O-rings included in the O-ring Kit (KT-05009) should be replaced.
5. After reassembly of the Proportioning Pumps torque the Assembly Bolts to 30ft-lbs (41Nm).

CAUTION! Use wooden or plastic tools or a brass brush for cleaning. Do not use metal or abrasive tools that can scratch the contact surfaces.

16.8 METERING PUMP REMOVAL

NOTE! When removing the Poly side pump, skip steps 3 and 4.

1. Put machine in retract position.
2. Turn off main power and discharge all pressure gauges to zero.
3. Disconnect the bottom elbow on the Iso lube cylinder and drain all Iso lube.
4. Disconnect the top hose going to Iso lube cylinder then uninstall red plug.
5. Remove clevis pin.
6. Disconnect the hose on the pump flange.
7. Disconnect the Y-strainer from elbow.
8. Carefully remove the four bolts and washers while holding the pump in place.

16.9 MATERIAL HEATER

WARNING! Before performing any maintenance, make sure the Main Power Switch is OFF and incoming power is locked OFF. NEVER access the inside of the Control Panel with the Proportioner power supply ON. The Heaters are components that reach high temperatures; you must wait until they have cooled before handling and bleed all material pressure to zero.

16.10 THERMOCOUPLE REPLACEMENT

NOTE! The Thermocouple is assembled into the Connector Body with a Ferrule and Nut. Once inserted into the Body and the Nut is tightened, the Ferrule locks to the Thermocouple and does not allow it to be relocated or moved. The location of the Thermocouple is very important and must be done correctly before tightening the Nut.




Figure 105: Thermocouple Identification

1. Unscrew the Nut that holds the defective Thermocouple and remove from the Body. Disconnect Thermocouple wiring located under the Top Cover of the Heater. Remove Body and discard.
2. Install Heating Element and Spring if also removed.
3. Install Connector Body into Heater using an open-end wrench and tighten to prevent leakage. Teflon Tape or appropriate Thread Sealant should be used.
4. Slide the Nut and the Ferrule over the Thermocouple and insert this assembly into the Connector Body until it comes into **positive physical contact** with the Heating Rod. Make sure the Spring does not prevent the Thermocouple from making contact with the Heating Rod.
5. Slowly tighten the Nut using an open-end wrench, ensuring the Thermocouple maintains positive physical contact with the Heating Rod.
6. Reinstall the Thermocouple wires.

WARNING! Before performing any maintenance, make sure the Main Power Switch is OFF and incoming power is locked OFF. NEVER access the inside of the Control Panel with the Proportioner power supply ON. The Heaters are components that reach high temperatures; you must wait until they have cooled before handling and bleed all material pressure to zero.

To replace a defect Heating Rod, proceed as follows:

1. Ensure Main Power Switch is OFF and incoming power is locked OFF. Depressurize proportioner and remove the Cover on Heater.

WARNING! If the Heating Rod to be replaced is the one in contact with the Thermocouple, it is necessary to remove the Thermocouple first. Do not loosen or tighten Thermocouple Body.

2. Disconnect the suspect Heating Rod from the wire connections and test the Heating Rod again for proper electrical resistance.

Heating Rod	Ohm Measurement per Rod	Total Ohm Measurement per Fluid Side
1500 WATT	32.4 Ω	10.8 Ω

3. Unscrew the Heating Rod and remove from the Heater Block along with its Spring and inspect; it must be smooth and shiny in appearance. If it is blackened or has material adhered to it replace the Heating Rod, even if ohm reading is acceptable.
4. Apply Teflon Tape or appropriate Thread Sealant to the Heating Rod thread and assemble Heating Rod and Spring into the Heater Block. Tighten securely to 110 ft/lbs. (150 Nm)
5. If necessary, carefully re-install Thermocouple ensuring positive physical contact with the Heating Rod. Make sure the Spring does not prevent the Thermocouple from making contact with the Heating Rod. Tighten Nut with open-end wrench.
6. Reconnect wire connections and replace Cover.
7. Ensure Heater is full of material prior to electrical testing.

17 HYDRAULIC OIL SPECIFICATIONS

Recommended Hydraulic Oil Specification:

ISO/ASTM Viscosity Grade 32

Viscosity:

28.8 – 35.2 SSU at 104°F Rust and Oxidation Inhibited

17.1 MANUFACTURERS

- Mobil DTE24 (Recommended)
- Cook's Albavis 8
- Ashland - Valvoline AW15
- Shell – Tellus 32(25)
- Sun Oil - Sunvis 706
- Chevron ISO32
- American Oil & Supply – PQ Iso 32
- Gulf Oil – Harmony 32AW (43AW)
- Atlantic Richfield – Duro AWS-150
- BP Oil – Energol HLP-C32
- Exxon – Nuto H-32(44)
- Margolis – T.I.P.100-15-7
- Fiske Bros. – Lubriplate Hyd. #0
- SW – Alemite Hydraulic HD #0
- Texaco – Rando HD32 (HD A0)
- White & Bagley – EP Hyd. 150

18 PARTS IDENTIFICATION

18.1 FRAME ASSEMBLY




Figure 106: Frame Assembly (203097)

FRAME ASSEMBLY (203097)			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	6	201230	RECEPTACLE, 82 QUARTER TURN
2	4	201583	SHCS, 3/8-16 X 2.000, 18-8 SS
3	8	207899	BHCS, 1/4-20 X 0.750, 18-8 SS
4	4	202146	HHCS, 1/4-20 X 0.750, ZP GRD8
5	8	202151	HHCS, 5/16-18 X 1.000, ZP GRD8
6	8	202204	HHCS, 5/16-18 X 0.875, ZP GRD8
7	16	202401	WASHER, FLAT, SAE, 1/4, ZP
8	16	202553	WASHER, LOCK, 1/4, 1/4, ZP
9	20	202554	WASHER, LOCK, 5/16, ZP
10	4	202555	WASHER, LOCK, 3/8, ZP
11	28	202556	WASHER, FLAT, SAE, 5/16, ZP
12	4	202557	WASHER, FLAT, USS, 3/8, ZP
13	4	202982	WASHER, TANK MOUNT, PREMIER
14	1	202986	TANK MOUNT ASSY, PREMIER
15	1	202987	FRAME, PUMP MOUNT, PREMIER
16	1	203003	BASE FRAME, PREMIER
17	1	203012	SUPPORT, PUMP FRAME, PREMIER
18	2	203019	SUPPORT, BASE COVER, PREMIER
19	2	203033	SIDE COVER, PREMIER
20	1	203141	WELDMENT, TANK, PREMIER
21	8	203142	NUT, NYLOCK, 5/16-18, GRD 5
22	4	203143	FHCS, 3/8-16 X 1.250, ZP
23	12	203145	HHCS, 1/4-20 X 0.500, ZP GRD 5
24	4	203146	HHCS, 3/8-16 X 1.500, ZP GRD8
25	4	203147	HHCS, 5/16-18 X 0.750, ZP GRD8
26	1	HI-00001A	SIGHT GAUGE, TANK
27	1	HI-00002-A-1	GROMMET, TANK TOP, MODIFIED 1"
28	1	HI-00014-03A	GASKET, TANK TOP
29	1	HI-00047A	HYDRAULIC FILL STRAINER
30	1	HI-05306	TANK PUMP DRAIN TUBE
31	1	HI-05308	TANK DISCHARGE TUBE
32	1	HI-05317	BULKHEAD UNION, 3/8 JIC
33	1	HI-05319	BULKHEAD UNION, 1/2 JIC
34	1	RM-05700-11	TANK LID
35	2	RM-05700-15	MOTOR MOUNT BARS
36	4	TN-05704	4" CASTER

18.2 PROX SENSOR ASSEMBLY




Figure 107: Prox. Sensor Assembly (RM-230)

PROX SENSOR ASSEMBLY (RM-230)			
ITEM	QTY	PART NUMBER	DESCRIPTION
1*	2	202400	HHCS, 1/4-20 X 1.25, ZP GRD 5
2*	2	202401	WASHER, FLAT, SAE, 1/4, ZP
3*	2	202553	WASHER, LOCK, 1/4, ZP
4	2	EL-153	12MM PROX SWITCH
	4		M12 X 1.75 JAM NUT
	2		LOCK WASHER
5	2	EL-153-01	HEX JAM NUT, M10

* Indicates parts not included in RM-230 assembly, hardware located in final assembly.

18.3 PUMP-LINE ASSEMBLY




Figure 108: Pump-Line Assembly (PL-1A)

PUMP LINE ASSEMBLY - LOW PRESSURE (PL-1A)			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	PU-05003	LUBE CYLINDER
2	2	PU-05007	PIN, CLEVIS W/ CLIP
2.1	1	201167	E-CLIP, 7/32"
2.2	1	202198	PIN, CLEVIS
3	8	PU-05008	MOUNTING BOLT
4	8	PU-05008-1	SERRATED WASHER 5/16

Note: Items 2.1 & 2.2 can be ordered separately but are all included in purchase of Item 2 (PU-05007).

18.3.1 PUMP BASE REBUILD KITS

PUMP BASE UPGRADE KIT, SPLIT SLEEVE (202305)		
QTY	PART NUMBER	DESCRIPTION
1	202220	SLEEVE, PUMP BASE
1	202221	RETAINER NUT, PUMP BASE
1	202228	O-RING -218, TEFLON, 55D
1	PU-01003-IG	GASKET, DISCHARGE BALL SEAT
1	PU-05023-1	GASKET, PUMP RETAINER NUT
1	PU-05024	SEAT, DISCHARGE
1	PU-05025	BALL, DISCHARGE

PUMP BASE REPAIR KIT, SPLIT SLEEVE (202355)		
QTY	PART NUMBER	DESCRIPTION
1	200706	CHECK VALVE REMOVAL TOOL, PUMP
1	202228	PIPE PLUG 1/4-18, 7/8 TAPER
1	HI-05067	O-RING, -028, VITON, 90D
1	OR-00045A	O-RING, -218, TEFLON, 55D
1	OR-00051B	GASKET, INLET BALL SEAT
1	PU-01003-DG	GASKET, DISCHARGE BALL SEAT
1	PU-01003-IG	SEAT, INLET
1	PU-05019	BALL, INLET
1	PU-05020	SPRING
1	PU-05021	GASKET, PUMP RETAINER NUT
1	PU-05023-1	SEAT, DISCHARGE
1	PU-05024	BALL, DISCHARGE
1	PU-05025	TOOL, BALL SEAT REMOVAL
1	TL-02	O-RING -218, AFLAS 80D

PUMPLINE, O-RING KIT (KT-05009)		
QTY	PART NUMBER	DESCRIPTION
4	OR-00011A	O-RING, 12 X 12MM ID
4	OR-00020A	O-RING, -133, VITON, 90D
2	OR-00044A	O-RING, -218, AFLAS, 80D
2	OR-00046A	GASKET, CYLINDER FLANGE
1	OR-00051B	O-RING -024
2	PU-01013A	O-RING -136, VITON

18.4 HYDRAULIC CYLINDER ASSEMBLY




Figure 109: Hydraulic Cylinder Assembly (HI-01)

HYDRAULIC CYLINDER ASSEMBLY (HI-01)			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	4	202779	SHCS, #10-24 X 2.000, ZP ALY STL
2	4	202780	SHCS, 5/16-18 X 1.750, ZP ALY STL
3	1	HI-05003	DIRECTIONAL VALVE
4	2	HI-05012	FTG, -08 ORB X -08 JIC, STL
5	1	HI-05025A	HYD CYL ASSY, BASE, CLASSICS
6	1	HI-05040	GAUAGE, PRESSURE, 0-2000PSI
7	1	HI-05070	HYDRAULIC MANIFOLD, CLASSIC
8	2	HI-05070-4	PLUG, -06 ORB, STL
9	1	OR-00020A	#136 VITON LUBE CYLINDER O-RING
10	2	OR-00038A	2MMX12.5MM 75 VITON BROWN
11	1	OR-00044A	O-RING #024; LUBE CYLINDER
12	1	PU-05004	END CAP; CYLINDER
13	1	PU-05005	BAFFLE
14	1	PU-05006	CLEVIS, HYDRAULIC
15	1	PU-05009	PLATE; REVERSING SWITCH
16	1	PU-05010	BUSHING

18.4.1 HYDRAULIC CYLINDER REBUILD KIT

HYDRAULIC CYLINDER REBUILD KIT (KT-05025)			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	2	HI-05025-1	U CUP
2	2	HI-05025-2	BACK-UP RING, PISTON
3	1	HI-05025-3	WEAR RING
4	2	HI-05025-4	WIPER, ROD
5	2	HI-05025-5	SHAFT SEAL
6	2	HI-05025-6	BACK-UP RING, BUSHING
7	2	OR-00038A	2MM X 12.5MM, 75 VITON BROWN
8	2	OR-00039A	O-RING -218 HYD CYLINDER ROD
9	2	OR-00040A	O-RING -036 HYD CYLINDER


18.4.2 HYDRAULIC CYLINDER ASSEMBLY BASE

Figure 110: Hydraulic Cylinder Assembly Base (HI-05025A)

HYDRAULIC CYLINDER ASSEMBLY BASE (HI-05025A)			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	2	HI-05025-1	U CUP, HYDRAULIC PISTON
2	2	HI-05025-2	BACK-UP RING, HYD PISTON
3	1	HI-05025-3	WEAR RING, HYD PISTON
4	2	HI-05025-4	ROD WISPER, BUSHING, HYD CYL
5	2	HI-05025-5	SHAFT SEAL, BUSHING, HYD CYL
6	2	HI-05025-6	BACK-UP RING, BUSHING, HYD CYL
7	1	HI-05025-7	PISTON, HYDRAULIC, CLSC
8	1	HI-05025-8	CYLINDER, HYDRAULIC, CLSC
9	2	HI-05025-9	PORT BLOCK, HYDRAULIC, CLSC
10	2	HI-05025-10	RETAINER FLANGE, HYD CYL, CLSC
11	7	HI-05025-11	STANDOFF, HEX, HYD CYL, CLSC
12	1	HI-05025-12	STANDOFF, REVERSING SWITCH
13	2	HI-05025-13	BUSHING, HYD CYL
14	4	HI-05025-14	TIE ROD, 5/16-24 X 9.375
15	2	OR-00039A	O-RING, #218, VITON
16	2	OR-00040A	O-RING, #036, VITON




Figure 111: Hydraulic Seal Detail View




Figure 112: Hydraulic Piston Detail View

18.5 A SINGLE PUMP ASSEMBLY




Figure 113: A Single Pump Assembly (PU-05001-120)

A SINGLE PUMP ASSEMBLY (PU-05001-120)			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	202520	PUMP BASE ASSEMBLY, CLASSICS
2	1	HI-05016	3/4 NPTM X 3/4 NPTF SW
3	1	HI-05038	1/4 NPT X 9/16-18 JIC 90 DEG E
4	2	OR-00011A	O-RING; CROSSOVER TUBE #014
5	1	OR-00020A	#136 VITON LUBE CYLINDER O-RING
6	2	OR-00046A	O-RING #133; VITON 90D PUMP CYL
7	1	PU-01013A	CYLINDER FLANGE GASKET
8	1	PU-05013	“A” PACKING RETAINER FLANGE
9	1	PU-05017	CROSSOVER TUBE
10	4	PU-05026	TIE ROD; 3/8-24 X 10-3/8
11	4	PU-05027	WASHER
12	4	PU-05028	NUT

18.5.1 A SINGLE REBUILD KIT




Figure 114: A Single Pump Cross Section

A PUMP REBUILD KIT (KT-07000)		
QTY	PART NUMBER	DESCRIPTION
1	KT-01016A-012	PISTON SEAL, 120 PUMP
2	OR-00011A	O-RING, 12 X 12MM ID
2	OR-00020A	O-RING -136, VITON, 90D
1	OR-00044A	O-RING -024
2	OR-00045A	O-RING -028, VITON, 90D
2	OR-00046A	O-RING -133, VITON, 90D
1	OR-00051B	O-RING -133, AFLAS 80D
1	PU-01013A	GASKET, CYLINDER FLANGE
1	PU-01003-DG	GASKET, INLET BALL SEAT
1	PU-01003-IG	GASKET, DISCHARGE BALL SEAT
1	PU-03000	TRIPLE LIP SEAL, 120 PUMP
1	PU-03005	SHAFT BEARING, 120 PUMP
1	PU-03017	RETAINING RING, 40 PUMP, A SIDE
1	PU-03019	BULLET, 120 PUMP
1	PU-03021	SEAL TOOL, A SIDE
1	PU-05023-1	GASKET, PUMP RETAINER NUT
1	PU-05029	PIN, 120 PUMP
1	PU-05030	SNAP RING, 120 PUMP
1	PU-05041	PISTON BEARING, 120 PUMP
1	RA-00065A	PLUG, PUMP CYLINDER
2	TN-04199	SHCS, 6/8-24 X 2.50

18.6 B SINGLE PUMP ASSEMBLY




Figure 115: B Single Pump Assembly (PU-05002-120)

B SINGLE PUMP ASSEMBLY (PU-05002-120)			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	202520	PUMP BASE ASSEMBLY, CLASSICS
2	1	HI-05016	3/4 NPTM X 3/4 NPTF SW
3	1	HI-05038	1/4 NPT X 9/16-18 JIC 90 DEG E
4	2	OR-00011A	O-RING; CROSSOVER TUBE #014
5	2	OR-00046A	O-RING #133; VITON 90D PUMP CYL
6	1	PU-01013A	CYLINDER FLANGE GASKET
7	1	PU-05017	CROSSOVER TUBE
8	4	PU-05026	TIE ROD; 3/8-24 X 10-3/8
9	4	PU-05027	WASHER
10	4	PU-05028	NUT
11	1	TN-04186	GREASE FITTING, 1/4-28

18.6.1 B SINGLE PUMP SEALS




Figure 116: B Single Pump Cross Section

B PUMP REBUILD KIT (KT-07001)		
QTY	PART NUMBER	DESCRIPTION
1	KT-01016A-012	PISTON SEAL, 120 PUMP
2	OR-00011A	O-RING, 12 X 12MM ID
2	OR-00045A	O-RING -028, VITON, 90D
2	OR-00046A	O-RING -133, VITON, 90D
1	OR-00051B	O-RING -133, AFLAS 80D
1	PU-01013A	GASKET, CYLINDER FLANGE
1	PU-01003-DG	GASKET, INLET BALL SEAT
1	PU-01003-IG	GASKET, DISCHARGE BALL SEAT
1	PU-03000	TRIPLE LIP SEAL, 120 PUMP
1	PU-03010	SHAFT BEARING, 120 PUMP
1	PU-03019	BULLET, 120 PUMP
1	PU-05023-1	GASKET, PUMP RETAINER NUT
1	PU-05029	PIN, 120 PUMP
1	PU-05030	SNAP RING, 120 PUMP
1	PU-05041	PISTON BEARING, 120 PUMP
2	TN-04199	SHCS, 6/8-24 X 2.50

18.7 A & B PUMP BASE ASSEMBLY




Figure 117: A & B Pump Base Assembly (202520)

A & B PUMP BASE ASSEMBLY (202520)			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	202220	SLEEVE, PUMP BASE, CLSC
2	1	202221	RETAINING NUT, PUMP BASE, CLSC
3	1	202228	O-RING, TEFLON, -218, 55D
4	2	HI-05067	PIPE PLUG 1/4"-18; 7/8 TAPER S
5	1	PU-01003-DG	INLET BALL SEAT GASKET
6	1	PU-01003-IG	GASKET, DISCHARGE BALL SEAT, CLSC
7	1	PU-05018	PUMP BASE
8	1	PU-05019	SEAT, INLET
9	1	PU-05020	BALL, INLET
10	1	PU-05021	SPRING, PUMP BASE
11	1	PU-05023-1	GASKET, PUMP RETAINER NUT, CLSC
12	1	PU-05024	SEAT, DISCHARGE, CLSC
13	1	PU-05025	BALL, DISCHARGE, CLSC

18.8 INLET MONITORING ASSEMBLY




Figure 118: Inlet Monitoring Assembly (202237)

INLET MONITORING ASSEMBLY (202237)			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	2	202236	FTG, CROSS, 3/4 NPTF, STL
2	1	HI-05015	FTG, 90° ELBOW, 3/4 MNPTF, STL
3	2	HI-05017	FTG, UNION, 3/4 MNPTF, STL
4	4	HI-05053	FTG, RDCR, 3/4 MNPTF, 1/4 FNPTF, STL
5	1	HI-05055	GAUGE, TEMP, 0-200 F
6	1	HI-05103	PRESS GAUGE 0-600 PSI

18.9 Y-STRAINER ASSEMBLY "A" SIDE




Figure 119: Y-Strainer Assembly "A" Side (YS-1)

Y-STRAINER ASSEMBLY "A" SIDE (YS-1)			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	HI-05016	3/4 NPTM X 3/4 NPTF SW
2	1	HI-05017	3/4 MNPT UNION
3	1	HI-05018	3/4 NPT X 1/2 NPT SW
4	1	RA-00074-00A	Y-STRAINER ASSY
4.1	1	RA-00074-03-XXA	FILTER SCREEN 30/60/80
4.2	1	SP-00009A	FILTER SCREEN SPRING
4.3	1	RA-00074-02A	GASKET, Y-STRAINER
5	1	RA-00078A	3/4 BALL VALVE SS

Note: Items 4.1-4.3 can be ordered separately but are all included in purchase of Item 4 (RA-00074-00A).

18.10 Y-STRAINER ASSEMBLY "B" SIDE




Figure 120: Y-Strainer Assembly "B" Side (YS-2)

Y-Strainer Assembly "B" Side (YS-2)			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	2	HI-05016	3/4 NPTM X 3/4 NPTF SW
2	1	HI-05017	3/4 MNPT UNION
3	1	RA-00074-00A	Y-STRAINER ASSY
3.1	1	RA-00074-03-XXA	FILTER SCREEN 30/60/80
3.2	1	SP-00009A	FILTER SCREEN SPRING
3.3	1	RA-00074-02A	GASKET, Y-STRAINER
4	1	RA-00078A	3/4 BALL VALVE SS

Note: Items 3.1-3.3 can be ordered separately but are all included in purchase of Item 3 (RA-00074-00A).

18.11 HEATER ASSEMBLY




Figure 121: Heater Assembly, 6 Rod - A




Figure 122: Heater Assembly, 6 Rod - B

PREHEATER ASSEMBLY, 6-ROD, (9kW)			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	09-03200	PRESSURE SWITCH
2	2	200977	FERRULE, 8 AWG, RED
3	2	201561	BHCS, #6-32 X 0.375, 18-8 SS
4	4	201899	BHCS, 1/4-20 X 0.750, 18-8 SS
5	4	201902	BHCS, 1/4-20 X 1.000, 18-8 SS
6	1	202190	CABLE, OP, PH25/40
7	1	203221	FTG, 90° ELBOW, 1/2 MPTF X 3/8 NPSM, STL
8	1	EL-00006A	SWITCH, THERMAL LIMIT OVERTEMP
9	1	EL-00053	SOLENOID VALVE GASKET
10	1	GM-05423-1	HEATER; BODY
11	6	GM-05423-7	HTR, SPRING 18", CBN STL
12	2	GM-05423-9	PHENOLIC STANDOFF; BOTTOM FRONT
13	2	GM-05423-10	PHENOLIC STANDOFF; BOTTOM BACK
14	6	GM-05423-1500	FIRE ROD; 1500W, 3/4 NPT, 17.5"
15*	1	HI-05020	THERMOCOUPLE NUT, FERRULE, & BODY
16*	1	HI-05021	E TYPE THERMOCOUPLE
17	2	HI-05032	1/2 MPT LONG HEX NIPPLE
18	3	HI-05033	PLUG, -08 ORB, STL
19	6	HI-05034	PLUG, -12 ORB, STL
20	3	HI-05035	1/2 MPT FLUSH SEAL, 1/4 NPT, STL
21	1	HI-05036	PLUG, FLUSH SEAL, 1/4 NPT, STL
22	1	HI-05038	1/4 NPT X 9/16-18 JIC 90 DEG E
23	2	HI-05046-1/2	MANIFOLD, 1/4 OUTLET
24	1	RM-05700-17	HEATER BOTTOM, MOUNTING PLATE

* Indicates part included in KT-05021: Heater Thermocouple Kit.




Figure 123: 6 Rod Heater Assembly, A and B Side

HEATER ASSEMBLY			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	203122	HEATER ASSY "A" SIDE, 9.0 kW
2	1	203125	HEATER ASSY "B" SIDE, 9.0 kW

18.12 PRESSURE TRANSDUCER ASSEMBLY




Figure 124: Pressure Transducer Assembly (EL-200)

PRESSURE TRANSDUCER ASSEMBLY (EL-200)			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	EL-195	0-500 PRESS TRANSDUCER
2	1	Hi-05006-5	PARKER 6 R6X-S BP – PRESSURE TEE
3	1	HI-05006-6	1/4 NPT X 6 JIC GAUGE FITTING

C

18.13 MOTOR-LINE ASSEMBLY




Figure 125: Motor-Line Assembly (ML-4)

MOTOR-LINE ASSEMBLY (ML-4)			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	2	202152	HHCS, 3/8-16 X 1.000, ZP GRD8
2	4	202194	WASHER, FLAT, 1/2, ZP SAE
3	4	202195	WASHER, LOCK, 1/2, ZP
4	4	202207	HHCS, 1/2-13 X 1.25, ZP GRD8
5	2	202555	WASHER, LOCK, 3/8, ZP
6	1	EL-05223	ELECTRIC MOTOR, 5HP, 3PH, 50/60HZ (ML-4)
7	1	HI-00005-03	ACCESS COVER
8	1	HI-00049A	1X16 BLACK PIPE FOR HYDRAULIC
9	1	HI-00065-02	COUPLER HUB, 1 1/8
10	1	HI-00065-03	COUPLER HUB, 3/4
11	1	HI-00067	MAGNALOY INDERT, 9.45HP
12	1	HI-05001	BELL HOUSING
13	1	HI-05004	HYDRAULIC PUMP
14	1	HI-05004-1	CONTROL KNOB, HYD PUMP
15	1	HI-05006-3	90 DEGREE ½ JIC X #12 ORB
16	1	HI-05007	6 ORB X 6 JIC 90 DEGREE
17	1	HI-05009	1-1/16-12 OUTLET FLANGE
18	1	HI-05010	1" NPT INLET FLANGE

18.14 A FLOW METER PIPES




Figure 126: Flow Meter Pipe - A-Side (203232)

Flow Meter Pipe Assembly, A-Side (203232)			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	2	203219	PIPE, 3/8 NPT, 8.000", SS
2	4	203220	FTG, STRT, 3/8, MPTF X 3/8 FPTF, STL
3	4	203222	FTG, STRT, 3/8, MPTF X 1/4 FPTF, STL
4	4	HI-05027	1/4 NPT X 1/2-20 JIC 45 DEG EL

18.15 B FLOW METER PIPES




Figure 127: Flow Meter Pipe - B-Side (203233)

Flow Meter Pipe Assembly, B-Side (203233)			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	2	203219	PIPE, 3/8 NPT, 8.000", SS
2	4	203220	FTG, STRT, 3/8, MPTF X 3/8 FPTF, STL
3	4	203222	FTG, STRT, 3/8, MPTF X 1/4 FPTF, STL
4	4	HI-05026	1/4 NPT X 9/16-18 JIC 45 DEG EL

18.16 CONSOLE ASSEMBLY




Figure 128: Console Assembly - A




Figure 129: Console Assembly - B





Figure 130: Console Assembly - C

CONSOLE ASSEMBLY (203052)			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	300 IN	201011	CABLE, GY, 3X 22AWG, UNSHIELDED
2	1	201218	E-STOP PUSH-TWIST
3	1	201219	CONTACT BLOCK, NON-LIGHTED SPST-NC
4	1	201228	LIGHT UNIT, GREEN, 240VAC
5	1	201567	FAN, DC BRUSHLESS, 24 VDC
6	1	201920	COVER, FAN, 92MM
7	1	202148	BOTTOM PLATE WIRES
8	1	202267	CAP, USB, PHD(X)-2
9	2	202269	CABLE, CAT5E, 24.000"
10	3	202290	GRMT, 1.500GW, 1.250ID, 0.093 GD, SBR
11	1	202342	USB STICK, 8GB
12	1	202343	MEMORY CARD, SDHD, 32GB
13	1	202503	WIRES, CONSOLE
14	6	202863	PHCS, #8-32 X 0.375, ZP
15	1	203028	TOUCHSCREEN, CAPACITIVE, 15 INCH
16	1	203041	WELDMENT, ENCLOSURE, PRMR
17	1	203042	COVER, HMI, PRMR
18	1	203043	COVER, PLC ACCESS, PRMR
19	1	203044	COVER, HINGED, PRMR
20	1	203048	BTM PLT ASSY, 3Ø, 220V, PRMR
21	1	203049	BOTTOM PLATE ASSY, PLC, PRMR
22	2	203112	STRAIGHT CONDUIT CONNECTOR, 1"
23	1	203113	CABLE, USB, WP, M-F, 0.5m
24	2	203114	BULKHEAD, SMA, WP, F-F
25	2	203115	WING STUD, 1/4 TURN, 075
26	2	203116	SPRING, 045 - 070, 1/4 TURN, SS
27	2	203118	SELF-EJECTING CUP, 1/4 TURN
28	2	203119	RETAINER, SPLIT, 1/4 TURN
29	2	203120	RECEPTACLE, 1/4 TURN, MINI SNAP-IN, .071 - .089
30	1	203121	BULKHEAD, RJ45, SOCKET
31	2	203123	HINGE, CONSTANT TORQUE, TYPE A
32	1	203124	HINGE, CONSTANT TORQUE, TYPE B
33	2	203127	CABLE, SMA, M-M, 12"
34	15	203129	NUT, K-LOCK, #10-32, ZP
35	4	203130	PHCS, #8-32 x 0.250, ZP
36	1	203236	ANTENNA, 90°, SMA
37	1	203264	FAN GUARD, PUSH ON, 92mm
38	1	203278	CABLE, CAT5E, 36.000"
39	1	23333	SECONDARY ESTOP CONTACT N/C
40	2	EL-00052	SOLENOID VALVE CONNECTOR
41	2	EL-00053	SOLENOID VALVE CONN GASKET

ITEM	QTY	PART NUMBER	DESCRIPTION
42	1	EL-00088-01A	HEYCO SR INCOMING POWER
43	1	EL-100	ROTARY DISCONNECT; 80A; 3 POLE
44	1	EL-103	DOOR MOUNTING KIT
45	1	EL-103 (CAP)	CAP, DOOR MOUNTING KIT
46	1	EL-103 (SHAFT)	SHAFT SELECTOR HANDLE
47	1	EL-105	SELECTOR HANDLE; RED
48	4	EL-105_1 (SCREW)	SCREW
49	4	EL-105_2 (WASHER)	WASHER
50	1	EL-105_3 (NUT)	NUT
51	1	EL-105_4 (GASKET)	GASKET
52	6	EL-158	MICRO CORDSET 90° CONNECTOR
53	1	EL-169	4 WIRE CORD GRIP
54	2	EL-170	TVS, 1500W, 22V, BI-DIRECTIONAL
55	3	EL-05230-02	STRAIGHT CONDUIT CONNECTOR, 3/4
56	1	LB-05006	LABEL, HIGH VOLTAGE
57	1 FT	RM-E20-7-510	THERMOCOUPLE WIRE, 20GA

18.16.1 HIGH VOLTAGE PLATE ASSEMBLY**Figure 131: High Voltage Plate Assembly (203048)**

HIGH VOLTAGE PLATE ASSEMBLY (203048)			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	202210	CONTACTOR, 32A, 24VDC, CG
2	1	202211	MOTOR OVERLOAD, CG
3	1	202291	GRMT, 1.625GW, 1.375ID, 0.125GD, SBR
4	6	202860	MARKER, TERMINAL BLOCK, 10.2MM
5	2	202862	MARKER, TERMINAL BLOCK, 16MM
6	1	203029	ROUTER, CELLULAR, VERIZON WIRELESS
7	1	203045	BOTTOM PLATE, HV, PREMIER
8	6	203057	TERMINAL BLOCK, PUSH-IN, 10.2MM
9	1	203058	END COVER, 10.2MM
10	1	203061	GRMT, 2.000GW, 1.625ID, 0.063GD, SBR
11	1	203062	CIRCUIT BREAKER, 7A, 2 POLE
12	20	203098	HHCS, SELF-TAP, #8-32 X 0.375, ZP
13	3	203279	DIST BLK, 125A, 6 TERM
14	1	203285	GROUND BR, 7 TERMINAL
15	57.125 IN	203286	WIRE DUCT, 1.000 X 3.150, PVC
16	1	203335	ETHERNET SWITCH 5 PORT
17	2	EL-35	RELAY, 100A, 480V
18	1	EL-125-CARLOS	CONTACTOR, 40A, 24V, W/ SURGE
19	1	EL-146	TERMINAL BLOCK, 16MM, GRND
20	22.000 IN	EL-147	DIN RAIL, 35 X 7.5MM
21	4	EL-152	END STOP, 35MM
22	3	EL-175	CIRCUIT BREAKER, 50A, 2 POLE
23	1	EL-182	CIRCUIT BREAKER, 32A, 3 POLE


18.16.2 PLC PLATE ASSEMBLY

Figure 132: PLC Plate Assembly (203049)

PLC PLATE ASSEMBLY (203049)			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	2	201045	TERMINAL BLOCK GROUND, PTC
2	1	201534	PLC, PHD MACHINES
3	1	201535	SLICE, ANALOG INPUT, 8 CHANNELS
4	1	201536	SLICE, DIGITAL INPUT, 16 CHANNELS
5	1	201537	SLICE, DIGITAL OUTPUT, 16 CHANNELS
6	1	201538	SLICE, THERMOCOUPLE INPUT, 4 CHANNEL
7	1	201539	SLICE, THERMOCOUPLE INPUT, 2 CHANNEL
8	1	201541	SLICE, I/O POWER FEED, 5-24VDC
9	1	202854	BRIDGE, PLUG-IN, 2-POS, 5.2MM
10	4	202859	MARKER, TERMINAL BLOCK, 5.2MM
11	1	203046	BOTTOM PLATE, LV, PREMIER
12	1	203053	POWER SUPPLY, 5A, 230VAC/24VDC
13	2	203054	DISTR BLOCK, 18 X 2.5MM BLK
14	1	203055	DISTR BLOCK, 18 X 2.5MM RED
15	1	203056	END COVER, PUSH-IN, 5.2MM
16	1	203223	SLICE, I/O LINK MASTER
17	14	203227	HHCS, SELF-TAP, #8-32 X 0.250, ZP
18	2	203334	DISTR BLOCK 18 X 2.5MM GRY
19	19.250 IN	EL-147	DIN RAIL, 35 X 7.5MM
20	28.750 IN	EL-149	WIRE DUCT, 1.0 X 2.25, GREY
21	6	EL-152	END STOP, 35MM

18.17 FINAL ASSEMBLY




Figure 133: Premier Final Assembly - A




Figure 134: Premier Final Assembly - B




Figure 135: Premier Final Assembly - C




Figure 136: Premier Final Assembly - D

PREMIER			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	4	200936	FERRULE, QD FEMALE, 18AWG, RD
2	4	201061	WASHER, FLAT, SAE, #8, 18-8 SS
3	8	201230	RECEPTACLE, 82 QUARTER TURN
4	5	201560	BHCS, 1/4-20 X 0.500, 18-8 SS
5	4	201588	WASHER, FLAT, 3/8, 18-8 SS
6	22	201633	BHCS, #8-32 X 0.375, 18-8 SS
7	2	202105	BHCS, 5/16-18 X 1.000, 18-8 SS
8	15	202146	HHCS, 1/4-20 X 0.750, ZP GRD 8
9	4	202151	HHCS, 5/16-18 X 1.000, ZP GRD8
10	4	202152	HHCS, 3/8-16 X 1.000, ZP GRD 8
11	4	202163	WASHER, 0.562 OD X .290ID, NEOPRENE
12	36	202191	BHCS, #8-32 X 0.250, 18-8 SS
13	2	202237	INLET ASSY, BASE, PREMIER
14	24	202341	NUT, NYLOCK, 1/4-20, GRD 5
15	2	202400	HHCS, 1/4-20 X 1.125, ZP GRD 5
16	33	202401	WASHER, FLAT, 1/4, ZP SAE
17	1	202455	BLEED VALVE KIT, CLASSICS
18	41	202553	WASHER, LOCK, 1/4, ZP
19	12	202554	WASHER, LOCK, 5/16, ZP
20	8	202555	WASHER, LOCK, 3/8, ZP
21	12	202556	WASHER, FLAT, 5/16, ZP SAE
22	4	202557	WASHER, FLAT, 3/8, ZP USS
23	1	202994	SIPPORT, PROX SW, PREMIER
24	1	202995	FRAME, UPPER, PREMIER
25	1	202999	TIE BLOCK, PREMIER
26	2	203000	TIE BLOCK CLAMP, PREMIER
27	1	203014	RH BASE, HEAT COVER, PREMIER
28	1	203015	RH HEATER COVER, PREMIER
39	1	203016	RH HEATER COVER, SIDE, PREMIER
30	1	203017	LH HEATER COVER, PREMIER
31	1	203018	LH HEATER COVER, SIDE, PREMIER
32	2	203023	WELDMENT, GUSSET, PREMIER
33	1	203024	ENCLOSURE SUPPORT, LOWER, PREMIER
34	2	203030	COVER SUPPORT, LOWER, PREMIER
35	1	203050	LH BASE, HEAT COVER, PREMIER
36	1	203052	CONSOLE, 3PH, 220V, PREMIER
37	1	203097	FRAME ASSEMBLY, PREMIER
38	2	203112	STRAIGHT CONDUIT CONNECTOR, 1"
39	1	203122	HEATER ASSY, 9 kW, A-SIDE
40	1	203125	HEATER ASSY, 9 kW, R-SIDE
41	30	203126	CONDUIT, FLEX, 1"
42	8	203144	HHCS, 1/4-20 X 3.500, ZP GRD8
43	4	203145	HHCS, 1/4-20 X 3.500, ZP GRD8
44	4	203147	HHCS, 1/4-20 X 2.000, ZP GRD 5

ITEM	QTY	PART NUMBER	DESCRIPTION
45	4	203149	HHCS, 3/8-16 X 1.750, ZP GRD8
46	24	203150	WASHER, FLAT, ASME, 1/4, ZP
47	4	203153	HHCS- 1/4-20 X 1.250, ZP GRD8
48	4	203154	HHCS- 1/4-20 X 2.000, ZP GRD8
49	4	203155	HHCS- 3/8-16 X 7.750, ZP GRD8
50	8	203156	SHCS, 1/4-20 X 4.000, ZP STL
51	8	203157	WASHER, LOCK, SHCS, 1/4, ZP
52	4	203158	BOLT, CRGE, 1/4-20 X 0.750, ZP GRD 8
53	4	203159	NUT, JAM, 1/4-20, ZP GRD 5
54	1	203161	ASSEMBLY, UTILITY PLATE. PREMIER
55	1	203181	HOSE, HYDRAULIC, 1/4" X 10"
56	1	203226	BRACKET, LUBE BOTTLE, PREMIER
57	2	203227	BRACKET, XMFR COVER, VERT, PREMIER
58	2	203228	BRACKET, XMFR COVER, ANG, PREMIER
59	1	203232	FM FTGS, A SIDE, PREMIER
60	1	203233	FM FTGS, R SIDE, PREMIER
61	2	203235	FHCS, 5/16-18 X 0.750, ZP
62	1	203274	DECAL, PLC COVER, PREMIER
63	1	203275	DECAL, XMFR, FRONT, PREMIER
64	1	203276	DECAL, XMFR, TOP, PRMR
65	1	203280	COVER ASSY, XMFR BASE, PRMR
66	1	203281	COVER, QT, XMFR, FRONT, PRMR
67	1	203282	COVER, QT, LEFT SIDE, TOP, PRMR
68	1	203283	COVER, QT, LEFT SIDE, PRMR
69	1	203284	COVER, QT, RIGHT SIDE, PRMR
70	1	203308	CABLE, FLOW METER, A, PRMR
71	1	203309	CABLE, FLOW METER, R, PRMR
72	2	203311	FLOW METER, CLAMP-IN, UT, PRG
73	4	203353	SPACER, 3/8 X .625", LDPE
74	2	EL-63	PREHEATER ELECTRICAL CONNECTOR
75	4	EL-195	0-5000 PRESS TRANSDUCER
76	1	EL-05226	120V TRANSFORMER
77	2	EL-05220-02	120V TRANSFORMER
78	1	EL-05230-03	RT ANGLE CONDUIT CONNECTOR
79	2	EL-05233	GROMMET, REVERSING SWITCH
80	2	HI-05006-5	PARKER 6 R6X-S BP-PRESSURE T
81	2	HI-05006-6	1/4 NPT X 6 JIC GAUGE FITTING
82	1	HI-05013	HYD TANK RETURN HOSE, 1/2" X 23"
83	2	HI-05020	THERMOCOUPLE NUT, FERRULE, & BODY
84	2	HI-05021	E TYPE THERMOCOUPLE
85	2	HI-05028	PRESSURE GAUGE 0-3000 PSI
86	34.679 IN	HI-05347	3/8 NPT X 6 JIC 90 DEGREE
87	15.340 IN	HI-05347-1	HOSE, 16.25" HYD PUMP TO TANK
88	1	HI-05048	DRAIN PLUG
89	3	LB-05006	LABEL, HIGH VOLTAGE

ITEM	QTY	PART NUMBER	DESCRIPTION
90	2	LB-05007	LABEL, HOT SURFACE
91	1	LB-05009	LABEL, PINCH POINT
92	1	ML-4	MOTOR LINE ASSY, 5HP,3PH,60Hz
93	1	MQ-01009-01A	LUBE BOTTLE
94	1	MQ-01009-02A	LUBE BOTTLE LID
95	1	PL-1A	PUMPLINE ASSY, 120A/120R
96	1	PU-01027	ACTUATOR PLATE COVER
97	1	RA-00065A	PLUG, PUMP CYLINDER
98	1	RA-00066A	CBMB 90 DEG MALE ELBOW NPT
99	1	RA-00067A	CBMB 90 DEG MALE ELBOW NPT
100	1	RA-00068A	CHECK VALVE
101	10.000 FT	RM-00019	#6 HOSE HEAT WIRE
102	1	RM-230	MOUNTED PROXIMITY SWITCH ASSY
103	3.000 FT	RM-E-64-0100	POLYFLO TUBING, 3/8"
104	3.000 FT	RM-E-86-0100	POLYFLO TUBING, 1/2"
105	20.000 FT	RM-EL-05230-01	3CONDUIT, FLEX, 3/4"
106	1	YS-1	Y-STRAINER ASSY "A" SIDE
107	1	YS-2	Y-STRAINER ASSY "B" SIDE

18.18 PREMIER HOSES




Figure 137: Proportioner Hoses - Front




Figure 138: Proportioner Hoses - Back

PROPORTIONER HOSES			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	203181	HOSE, HYDRAULIC, 1/2" X 10"
2	1	HI-05013	HOSE, 1/2" X 17.50", STRT
3	2	HI-05047	HOSE, 3/8" X 20.00", STRT
4	1	HI-05047-1	HOSE, 3/8" X 16.25", STRT

18.18.1 HALF INCH HOSE KIT

HALF INCH HOSE KIT (200212)		
QTY	PART NUMBER	DESCRIPTION
1	RA-00010	ISO MALE MANIFOLD SETTINGS
1	RA-00011	POLY MALE MANIFOLD FITTING
1	RA-00019	JIC REDUCER 7/8-14 X 9/16-18
1	RA-00020	JIC REDUCER 3/4-16 X 1/2-20

18.19 LUBE BOTTLE COMPONENTS




Figure 139: Lube Bottle Components

LUBE BOTTLE COMPONENTS			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	GP-00960-1-GAL	PUMP LUBE GALLON
2	1	GP-00960-1-QRT	PUMP LUBE QUART
3	1	MA-00024A	1/2" X 43' PLASTIC TUBING, RETURN
4	1	MA-00025A	3/8" X 43' PLASTIC TUBING
5	1	MQ-01009-01A	LUBE BOTTLE
6	1	MQ-01009-02A	LUBE BOTTLE LID
7	1	RA-00068A	CHECK VALVE
8	1	RA-06008	CHECK VALVE, POLYTUBE, 3/8

LUBE ASSY KIT, PREMIER (202640)		
QTY	PART NUMBER	DESCRIPTION
1	MA-00024A-1	1/2" X 43' PLASTIC TUBING, RETURN
1	MA-00025A-1	3/8" X 43' PLASTIC TUBING
1	MQ-01009-01A	LUBE BOTTLE
1	MQ-01009-02A	LUBE BOTTLE LID
1	RA-00066A	MALE ELBOW, 3/8 TUBE X 1/4 NPT
1	RA-00067A	MALE ELBOW, 1/2 TUBE X 3/8 NPT
1	RA-00068A	CHECK VALVE
1	RA-06008	CHECK VALVE, POLYTUBE, 3/8

18.20 BLEED VALVES




Figure 140: Bleed Valves (202455)

BLEED VALVES (202455)			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	200226	5 JIC CAP
2	1	200227	6 JIC CAP
3	2	202430	BALL VALVE, 1/4 NPT, 5000 PSI
4	1	EL-00051A-4	1/4 NPT X 5 JIC
5	2	EL-00051A-5	1/4 NPT X 6 SWIVEL
6	3	EL-00051A-6	1/4 NPT X 6 JIC